




# Automation1 iXC4 and XC4 PWM Digital Drives

## HARDWARE MANUAL

Revision 2.05



## GLOBAL TECHNICAL SUPPORT

Go to the [Global Technical Support Portal](#) for information and support about your Aerotech, Inc. products. The website supplies software, product manuals, Help files, training schedules, and PC-to-PC remote technical support. If necessary, you can complete Product Return (RMA) forms and get information about repairs and spare or replacement parts. To get help immediately, contact a service office or your sales representative. Include your customer order number in your email or have it available before you call.

This manual contains proprietary information and may not be reproduced, disclosed, or used in whole or in part without the express written permission of Aerotech, Inc. Product names mentioned herein are used for identification purposes only and may be trademarks of their respective companies.

Copyright © 2018-2022, Aerotech, Inc., All rights reserved.



## Table of Contents

<b>Automation1 iXC4 and XC4 PWM Digital Drives</b> .....	<b>1</b>
Table of Contents .....	3
List of Figures .....	5
List of Tables .....	7
EU Declaration of Conformity .....	9
Agency Approvals .....	10
Safety Procedures and Warnings .....	11
Handling and Storage .....	13
Installation Overview .....	14
<b>Chapter 1: iXC4/XC4 Overview</b> .....	<b>17</b>
1.1. Electrical Specifications .....	21
1.1.1. System Power Requirements .....	22
1.2. Mechanical Specifications .....	23
1.2.1. Mounting and Cooling .....	23
1.2.2. Dimensions .....	24
1.3. Environmental Specifications .....	26
1.4. Drive and Software Compatibility .....	27
<b>Chapter 2: Installation and Configuration</b> .....	<b>29</b>
2.1. Input Power Connections .....	29
2.1.1. Control Supply Connector .....	29
2.1.2. Motor Supply Connector .....	30
2.1.3. Transformer Options .....	31
2.1.4. Minimizing Noise for EMC/CE Compliance .....	38
2.2. Motor Power Output Connector .....	39
2.2.1. Brushless Motor Connections .....	40
2.2.1.1. Brushless Motor Powered Motor and Feedback Phasing .....	41
2.2.1.2. Brushless Motor Unpowered Motor and Feedback Phasing .....	42
2.2.2. DC Brush Motor Connections .....	43
2.2.2.1. DC Brush Motor Phasing .....	43
2.2.3. Stepper Motor Connections .....	44
2.2.3.1. Stepper Motor Phasing .....	44
2.2.4. Three Phase Stepper Motor Connections .....	45
2.2.4.1. Stepper Motor Phasing .....	45
2.3. Feedback Connector .....	46
2.3.1. Primary Encoder Inputs .....	47
2.3.1.1. Square Wave Encoder (Primary) .....	48
2.3.1.2. Absolute Encoder (Primary) .....	49
2.3.1.3. Sine Wave Encoder (Primary) [-MX1 Option] .....	50
2.3.1.4. Encoder Phasing .....	52
2.3.2. Hall-Effect Inputs .....	53
2.3.3. Thermistor Input .....	54
2.3.4. Encoder Fault Input .....	55
2.3.5. End of Travel and Home Limit Inputs .....	56
2.3.5.1. End of Travel and Home Limit Phasing .....	58
2.3.6. Brake Outputs .....	59
2.4. Safe Torque Off Input (STO) .....	60
2.4.1. STO Standards .....	62
2.4.2. STO Functional Description .....	63
2.4.3. STO Startup Validation Testing .....	64
2.4.4. STO Diagnostics .....	65
2.5. Auxiliary I/O Connector .....	66
2.5.1. Auxiliary Encoder Inputs .....	67
2.5.1.1. Square Wave Encoder (Auxiliary) .....	68
2.5.1.2. Absolute Encoder (Auxiliary) .....	69
2.5.2. Position Synchronized Output (PSO) .....	70
2.5.3. Digital Outputs .....	72
2.5.4. Digital Inputs .....	75

2.5.5. High-Speed Inputs .....	77
2.5.6. Analog Output 0 .....	78
2.5.7. Analog Input 0 (Differential) .....	79
2.6. Brake Power Supply Connector .....	80
2.7. HyperWire Interface .....	81
2.8. External Shunt Option [-SX1] .....	82
2.9. Sync Port .....	84
2.10. Industrial Ethernet (iXC4 Only) .....	84
2.11. System Interconnection .....	85
2.12. PC Configuration and Operation Information .....	88
<b>Chapter 3: -EB1 Option Expansion Board .....</b>	<b>89</b>
3.1. Digital Outputs [-EB1] .....	90
3.2. Digital Inputs [-EB1] .....	94
3.3. Analog Outputs [-EB1] .....	97
3.4. Analog Inputs [-EB1] .....	98
3.5. PSO Interface [-EB1] .....	99
<b>Chapter 4: Cables and Accessories .....</b>	<b>101</b>
4.1. Joystick Interface .....	102
4.2. Handwheel Interface .....	104
<b>Chapter 5: Maintenance .....</b>	<b>105</b>
5.1. Preventative Maintenance .....	106
5.2. Fuse Specifications .....	107
<b>Appendix A: Warranty and Field Service .....</b>	<b>109</b>
<b>Appendix B: Revision History .....</b>	<b>111</b>
<b>Index .....</b>	<b>113</b>

## List of Figures

Figure 1-1:	iXC4 Digital Drive-Based Controller Labeled	17
Figure 1-2:	XC4 Digital Drive Labeled	18
Figure 1-3:	Functional Diagram	20
Figure 1-4:	Dimensions	24
Figure 1-5:	Dimensions [-EB1]	25
Figure 2-1:	Control Supply Connections	29
Figure 2-2:	Motor Supply Connections	30
Figure 2-3:	TV0.3-28-56-ST Transformer Control and Motor Power Wiring (40 VDC Bus)	32
Figure 2-4:	TV0.3-28-56-ST Transformer Control and Motor Power Wiring (80 VDC Bus)	33
Figure 2-5:	TV0.3-28-56-ST Transformer Control and Motor Power Wiring (160 VDC Bus)	34
Figure 2-6:	TV0.3-28 Transformer Control and Motor Power Wiring (40 VDC Bus)	35
Figure 2-7:	TV0.3-56 Transformer Control and Motor Power Wiring (80 VDC Bus)	36
Figure 2-8:	TM3/TM5 Transformer Control and Motor Power Wiring	37
Figure 2-9:	Brushless Motor Configuration	40
Figure 2-10:	Positive Motor Direction	41
Figure 2-11:	Encoder and Hall Signal Diagnostics	41
Figure 2-12:	Brushless Motor Phasing Oscilloscope Example	42
Figure 2-13:	Brushless Motor Phasing Goal	42
Figure 2-14:	DC Brush Motor Configuration	43
Figure 2-15:	Positive Motor Direction	43
Figure 2-16:	Stepper Motor Configuration	44
Figure 2-17:	Positive Motor Direction	44
Figure 2-18:	Three Phase Stepper Motor Configuration	45
Figure 2-19:	Positive Motor Direction	45
Figure 2-20:	Square Wave Encoder Schematic (Feedback Connector)	48
Figure 2-21:	Absolute Encoder Schematic (Feedback Connector)	49
Figure 2-22:	Sine Wave Encoder Phasing Reference Diagram	50
Figure 2-23:	Sine Wave Encoder Schematic (Feedback Connector)	51
Figure 2-24:	Encoder Phasing Reference Diagram (Standard)	52
Figure 2-25:	Position Feedback in the Diagnostic Display	52
Figure 2-26:	Hall-Effect Inputs Schematic (Feedback Connector)	53
Figure 2-27:	Thermistor Input Schematic (Feedback Connector)	54
Figure 2-28:	Encoder Fault Input Schematic (Feedback Connector)	55
Figure 2-29:	End of Travel and Home Limit Input Connections	57
Figure 2-30:	End of Travel and Home Limit Input Schematic (Feedback Connector)	57
Figure 2-31:	End of Travel and Home Limit Input Diagnostic Display	58
Figure 2-32:	Brake Connected to the 25-Pin Feedback Connector (Typical)	59
Figure 2-33:	Typical STO Configuration	61
Figure 2-34:	STO Timing	65
Figure 2-35:	Square Wave Encoder Interface (Aux I/O Connector)	68
Figure 2-36:	Absolute Encoder Schematic (Auxiliary I/O Connector)	69
Figure 2-37:	PSO Interface	71
Figure 2-38:	Digital Output Schematic (Aux I/O Connector)	73
Figure 2-39:	Digital Outputs Connected in Current Sourcing Mode	74
Figure 2-40:	Digital Outputs Connected in Current Sinking Mode	74
Figure 2-41:	Digital Inputs Schematic (Aux I/O Connector)	75
Figure 2-42:	Digital Inputs Connected to Current Sourcing Devices	76
Figure 2-43:	Digital Inputs Connected to Current Sinking Devices	76

Figure 2-44:	High-Speed Inputs .....	77
Figure 2-45:	Analog Output 0 Schematic .....	78
Figure 2-46:	Analog Input 0 Schematic .....	79
Figure 2-47:	Drive-Based System Wiring Drawing (Best Practice) .....	85
Figure 2-48:	PC-Based System Wiring Drawing (Best Practice) .....	85
Figure 2-49:	Drive-Based Controller System Interconnection (Best Practice) .....	86
Figure 2-50:	PC-Based Controller System Interconnection (Best Practice) .....	87
Figure 3-1:	-EB1 I/O Option Board Connectors (iXC4 shown) .....	89
Figure 3-2:	Digital Outputs Schematic [-EB1] .....	92
Figure 3-3:	Digital Outputs Connected in Current Sourcing Mode [-EB1] .....	93
Figure 3-4:	Digital Outputs Connected in Current Sinking Mode [-EB1] .....	93
Figure 3-5:	Digital Inputs Schematic [-EB1] .....	95
Figure 3-6:	Digital Inputs Connected to Current Sourcing (PNP) Devices [-EB1] .....	96
Figure 3-7:	Digital Inputs Connected to Current Sinking (NPN) Devices [-EB1] .....	96
Figure 3-8:	Analog Output Typical Connection [-EB1] .....	97
Figure 3-9:	Analog Input Typical Connection [-EB1] .....	98
Figure 3-10:	PSO Output Sources Current .....	100
Figure 3-11:	PSO Output Sinks Current .....	100
Figure 3-12:	PSO TTL Outputs Schematic .....	100
Figure 4-1:	Two Axis Joystick Interface (to the Aux I/O of two drives) .....	102
Figure 4-2:	Two Axis Joystick Interface (to the I/O board) .....	103
Figure 4-3:	Handwheel Interconnection to Aux I/O Connector .....	104
Figure 4-4:	Handwheel Interconnection to the Aux I/O through a BBA32 Module .....	104

## List of Tables

Table 1-1:	Features and Options .....	19
Table 1-2:	Electrical Specifications .....	21
Table 1-3:	Mounting Specifications .....	23
Table 1-4:	Environmental Specifications .....	26
Table 1-5:	Drive and Software Compatibility .....	27
Table 2-1:	Control Supply Wiring Specifications .....	29
Table 2-2:	Mating Connector Part Numbers for the Control Supply Connector .....	29
Table 2-3:	Motor Supply Connector Wiring Specifications .....	30
Table 2-4:	Mating Connector Part Numbers for the Motor Supply Connector .....	30
Table 2-5:	Nominal Motor Operating Voltages / Required AC Voltages .....	31
Table 2-6:	Transformer Options .....	31
Table 2-7:	Motor Power Output Connector Pinout .....	39
Table 2-8:	Mating Connector Part Numbers for the Motor Power Output Connector .....	39
Table 2-9:	Wire Colors for Aerotech-Supplied Brushless Motor Cables .....	40
Table 2-10:	Hall Signal Diagnostics .....	41
Table 2-11:	Wire Colors for Aerotech-Supplied DC Brush Motor Cables .....	43
Table 2-12:	Wire Colors for Aerotech-Supplied Stepper Motor Cables .....	44
Table 2-13:	Feedback Connector Pinout .....	46
Table 2-14:	Mating Connector Part Numbers for the Feedback Connector .....	46
Table 2-15:	Multiplier Options .....	47
Table 2-16:	Primary Encoder Input Pins on the Feedback Connector .....	47
Table 2-17:	Square Wave Encoder Specifications .....	48
Table 2-18:	Sine Wave Encoder Specifications .....	50
Table 2-19:	Hall-Effect Feedback Pins on the Feedback Connector .....	53
Table 2-20:	Thermistor Input Pin on the Feedback Connector .....	54
Table 2-21:	Encoder Fault Input Pin on the Feedback Connector .....	55
Table 2-22:	End of Travel and Home Limit Pins on the Feedback Connector .....	56
Table 2-23:	Brake Output Pins on the Feedback Connector .....	59
Table 2-24:	Brake Control Specifications .....	59
Table 2-25:	STO Connector Pinout .....	60
Table 2-26:	Mating Connector Part Numbers for the STO Connector .....	60
Table 2-27:	STO Electrical Specifications .....	61
Table 2-28:	STO Standards .....	62
Table 2-29:	STO Standards Data .....	62
Table 2-30:	STO Signal Delay .....	64
Table 2-31:	Motor Function Relative to STO Input State .....	64
Table 2-32:	STO Timing .....	65
Table 2-33:	Auxiliary I/O Connector Pinout .....	66
Table 2-34:	Mating Connector Part Numbers for the Auxiliary I/O Connector .....	66
Table 2-35:	Auxiliary Encoder Pins on the Auxiliary I/O Connector .....	67
Table 2-36:	Square Wave Encoder Specifications .....	68
Table 2-37:	PSO Specifications .....	70
Table 2-38:	PSO Pins on the Auxiliary I/O Connector .....	70
Table 2-39:	Digital Output Specifications .....	72
Table 2-40:	Digital Output Pins on the Auxiliary I/O Connector .....	72
Table 2-41:	Digital Input Specifications .....	75
Table 2-42:	Digital Input Pins on the Auxiliary I/O Connector .....	75
Table 2-43:	High-Speed Input Specifications .....	77

Table 2-44:	High-Speed Input Pins on the Auxiliary I/O Connector .....	77
Table 2-45:	Analog Output Specifications .....	78
Table 2-46:	Analog Output Pins on the Auxiliary I/O Connector .....	78
Table 2-47:	Analog Input Specifications .....	79
Table 2-48:	Analog Input Pins on the Auxiliary I/O Connector .....	79
Table 2-49:	Brake Power Supply Connector Pinout .....	80
Table 2-50:	Mating Connector Part Numbers for the Brake Power Supply Connector .....	80
Table 2-51:	HyperWire Card Part Number .....	81
Table 2-52:	HyperWire Cable Part Numbers .....	81
Table 2-53:	-SX1 Component Information .....	82
Table 2-54:	Maximum Additional Storage Energy for a Standard iXC4/XC4 .....	83
Table 2-55:	Sync-Related Functions .....	84
Table 2-56:	Sync Port Cables .....	84
Table 3-1:	Digital Output Specifications [-EB1] .....	90
Table 3-2:	Digital Output 1 Connector Pinout [-EB1] .....	91
Table 3-3:	Mating Connector Part Numbers for the Digital Output 1 Connector [-EB1] .....	91
Table 3-4:	Digital Output 2 Connector Pinout [-EB1] .....	91
Table 3-5:	Mating Connector Part Numbers for the Digital Output 2 Connector [-EB1] .....	91
Table 3-6:	Digital Input Specifications [-EB1] .....	94
Table 3-7:	Digital Input 1 Connector Pinout [-EB1] .....	94
Table 3-8:	Mating Connector Part Numbers for the Digital Input 1 Connector [-EB1] .....	94
Table 3-9:	Digital Input 2 Connector Pinout [-EB1] .....	95
Table 3-10:	Mating Connector Part Numbers for the Digital Input 2 Connector [-EB1] .....	95
Table 3-11:	Analog Output Specifications [-EB1] .....	97
Table 3-12:	Analog Output Connector Pinout [-EB1] .....	97
Table 3-13:	Mating Connector Part Numbers for the Analog Output Connector [-EB1] .....	97
Table 3-14:	Differential Analog Input Specifications [-EB1] .....	98
Table 3-15:	Analog Input Connector Pinout [-EB1] .....	98
Table 3-16:	Mating Connector Part Numbers for the Analog Input Connector [-EB1] .....	98
Table 3-17:	PSO Specifications [-EB1] .....	99
Table 3-18:	PSO Interface Connector Pinout [-EB1] .....	99
Table 3-19:	Mating Connector Part Numbers for the PSO Interface Connector [-EB1] .....	99
Table 4-1:	Standard Interconnection Cables .....	101
Table 5-1:	LED Description .....	105
Table 5-2:	Troubleshooting .....	105
Table 5-3:	Preventative Maintenance .....	106
Table 5-4:	Control Board Fuse Specifications .....	107

## EU Declaration of Conformity

**Manufacturer** Aerotech, Inc.  
**Address** 101 Zeta Drive  
 Pittsburgh, PA 15238-2811  
 USA  
**Product** iXC4/XC4  
**Model/Types** All

This is to certify that the aforementioned product is in accordance with the applicable requirements of the following directive(s):

2014/30/EU	Electromagnetic Compatibility (EMC)
2014/35/EU	Low Voltage Directive
2006/42/EC	Machinery Directive
2011/65/EU	RoHS 2 Directive
EU 2015/863	Amendment RoHS 3 Directive


and has been designed to be in conformity with the applicable requirements of the following standard(s) when installed and used in accordance with the manufacturer's supplied installation instructions.

EN 61010-1:2010/A1:2016	Safety Requirements for Electrical Equipment
EN 61800-3:2004/A1:2011	EMC Requirements for Power Drives
IEC 61800-5-1:2016	Electrical Safety for Power Drive Systems
IEC 61800-5-2:2016	Functional Safety for Power Drive Systems
EN 55011:2000/A2:2003	Conducted and Radiated Emissions
EN 55022:1998	Conducted and Radiated Emissions

**Authorized Representative**

 / Simon Smith, European Director  
 Aerotech Ltd  
 The Old Brick Kiln, Ramsdell, Tadley  
 Hampshire RG26 5PR  
 UK

**Engineer Verifying Compliance**

 / Alex Weibel  
 Aerotech, Inc.  
 101 Zeta Drive  
 Pittsburgh, PA 15238-2811  
 USA  
 2/28/2022

**Date**



## Agency Approvals

Aerotech tested its XC4 drives and found that they obey the standards that follow:



**IMPORTANT:** iXC4 certification is pending.

<b>Approval:</b>	CUS NRTL
<b>Approving Agency:</b>	TUV SUD America Inc.
<b>Certificate #:</b>	U8V 068995 0028 Rev. 02
<b>Standards:</b>	CAN/CSA-C22.2 No. 61010-1:2012, EN 61010-1:2010/A1:2016, UL 61010-1:2012
<b>Approval:</b>	Safety Components (STO)
<b>Approving Agency:</b>	TUV SUD
<b>Certificate #:</b>	Z10 068995 0030 Rev. 00
<b>Standards:</b>	EN ISO 13849-1:2015 (up to PL e), IEC 61508-1:2010 (up to SIL3), IEC 61508-2:2010 (up to SIL3), IEC 61800-5-2:2016, IEC 62061:2005 (up to SILCL3), IEC 62061:2005/AMD1:2012 (up to SILCL3), IEC 62061:2005/AMD2:2015 (up to SILCL3)

Visit <https://www.tuev-sued.de/product-testing/certificates> to view Aerotech's TÜV SÜD certificates. Type the certificate number listed above in the search bar or type "Aerotech" for a list of all Aerotech certificates.

## Safety Procedures and Warnings

**IMPORTANT:** This manual tells you how to carefully and correctly use and operate the drive.



- Read all parts of this manual before you install or operate the drive or before you do maintenance to your system.
- To prevent injury to you and damage to the equipment, obey the precautions in this manual.
- All specifications and illustrations are for reference only and were complete and accurate as of the release of this manual. To find the newest information about this product, refer to [www.aerotech.com](http://www.aerotech.com).

If you do not understand the information in this manual, contact Aerotech Global Technical Support.

**IMPORTANT:** This product has been designed for light industrial manufacturing or laboratory environments. If the product is used in a manner not specified by the manufacturer:



- The protection provided by the equipment could be impaired.
- The life expectancy of the product could be decreased.

Safety notes and symbols are placed throughout this manual to warn you of the potential risks at the moment of the safety note or if you fail to obey the safety note.



The voltage can cause shock, burn, or death.



You are at risk of physical injury.  
You could damage the drive.



A surface can be hot enough to burn you.



Your actions, the temperature of the system, or the condition of the atmosphere that surround the system could start a fire.



Components are sensitive to electrostatic discharge.



Unsecured cables could cause you to:

- trip and fall
- drag the product off of its mounting location
- damage the cable connections.



A blue circle symbol is an action or tip that you should obey. Some examples include:



- General tip
- Read the manual/section
- Wear protective safety equipment (eye protection, ear protection, gloves)
- If applicable, do not lift unassisted

**DANGER:** To decrease the risk of electrical shock, injury, death, and damage to the equipment, obey the precautions that follow.



1. Before you do maintenance to the equipment, disconnect the electrical power.
2. Restrict access to the drive when it is connected to a power source.
3. Do not connect or disconnect electrical components, wires, and cables while this product is connected to a power source.
4. Wait at least ten (10) minutes after removing the power supply before doing maintenance or an inspection. Otherwise, there is the danger of electric shock.
5. Supply each operator with the necessary protection from live electrical circuits.
6. Make sure that all components are grounded correctly and that they obey the local electrical safety requirements.
7. Install the necessary precautions to supply safety and protection to the operator.



**DANGER:** System travel can cause crush, shear, or pinch injuries. Restrict access to all motor and stage parts while your system is connected to a power source.



**WARNING:** To prevent damage to the equipment and decrease the risk of electrical shock and injury, obey the precautions that follow.

1. Make sure that all system cables are correctly attached and positioned.
2. Do not use the cables or the connectors to lift or move this product.
3. Use this product only in environments and operating conditions that are approved in this manual.
4. Only trained operators should operate this equipment.

## Handling and Storage

### Unpacking the drive



**IMPORTANT:** All electronic equipment and instrumentation is wrapped in antistatic material and packaged with desiccant. Ensure that the antistatic material is not damaged during unpacking.

Inspect the shipping container for any evidence of shipping damage. If any damage exists, notify the shipping carrier immediately.

Remove the packing list from the shipping container. Make sure that all the items specified on the packing list are contained within the package.

The documentation for the drive is on the included installation device. The documents include manuals, interconnection drawings, and other documentation pertaining to the system. Save this information for future reference. Additional information about the system is provided on the Serial and Power labels that are placed on the chassis.

The system serial number label contains important information such as the:

- Customer order number (please provide this number when requesting product support)
- Drawing number
- System part number

### Handling



**IMPORTANT:** It is the responsibility of the customer to safely and carefully lift and move the drive.

- Be careful when you move or transport the drive.
- Refer to [Section 1.2. Mechanical Specifications](#) for dimensions and weight specifications.
- Retain the shipping materials for future use.
- Transport or store the drive in its protective packaging.



**WARNING: Electrostatic Discharge (ESD) Sensitive Components!**

You could damage the power supply or drives if you fail to observe the correct ESD practices.

Wear an ESD wrist strap when you handle, install, or do service to the system assembly.

### Storage


Store the drive in the original shipping container. If the original packaging included ESD protective packaging, make sure to store the drive in it. The storage location must be dry, free of dust, free of vibrations, and flat.

Refer to [Section 1.3. Environmental Specifications](#)

## Installation Overview


The images that follow show the order in which to make connections and settings that are typical to the iXC4/XC4. If a custom interconnect drawing was supplied with your system, that drawing is on your Storage Device and shows as a line item on your Sales Order in the Integration section.

**Figure 1: Installation Connection Overview for the iXC4**



1	Connect the motor to the amplifier Motor Output connector.	<a href="#">Section 2.2.</a>
	Connect the motor to the amplifier Feedback connector.	<a href="#">Section 2.3.</a>
2	Connect the PC to the USB or Ethernet port.	N/A
3	Connect the next drive in the system to the HyperWire Out port.	<a href="#">Section 2.7.</a>
4	Connect additional I/O as required by your application (if you purchased the I/O option).	<a href="#">Section 2.5./</a> <a href="#">Chapter 3</a>
5	Connect the Safe Torque Off (STO).	<a href="#">Section 2.4.</a>
6	Connect the power supply to the Control Supply connector.	<a href="#">Section 2.1.1.</a>
7	Connect the motor power to the Motor Supply connector.	<a href="#">Section 2.1.2.</a>

Figure 2: Installation Connection Overview for the XC4



1	Connect the motor to the amplifier Motor Output connector.	<a href="#">Section 2.2.</a>
	Connect the motor to the amplifier Feedback connector.	<a href="#">Section 2.3.</a>
2	Connect a PC or drive-based controller HyperWire port to the HyperWire In port.	<a href="#">Section 2.7.</a>
3	Connect additional I/O as required by your application (if you purchased the I/O option).	<a href="#">Section 2.5./ Chapter 3</a>
4	Connect the Safe Torque Off (STO).	<a href="#">Section 2.4.</a>
5	Connect the power supply to the Control Supply connector.	<a href="#">Section 2.1.1.</a>
6	Connect the motor power to the Motor Supply connector.	<a href="#">Section 2.1.2.</a>

*This page intentionally left blank.*

# Chapter 1: iXC4/XC4 Overview

The iXC4 is a high-performance digital drive-based controller. It runs the Automation1-iSMC controller to generate commands for itself as well as for additional drives on the chain.

The XC4 is a high performance digital drive. The XC4 is based on the HyperWire communication protocol and receives commands from a PC or drive-based controller.

Both drives provide deterministic behavior, auto-identification, and are fully software configurable. A double precision floating point DSP controls the digital PID and current loops. Both drives offer standard Safe Torque Off (STO) inputs and optional Position Synchronized Output (PSO) outputs. And both drives are offered with an optional encoder interpolation feature (-MX1), an auxiliary encoder input for dual loop control, dedicated analog and digital I/O (expandable with the -EB1 option), and separate power connections for motor and control supply voltages.

**Figure 1-1: iXC4 Digital Drive-Based Controller Labeled**





Figure 1-2: XC4 Digital Drive Labeled




**Table 1-1: Features and Options**

Standard Features	
<ul style="list-style-type: none"> <li>• 100-240 VAC control supply inputs (Section 2.1.1.)</li> <li>• 0-240 VAC motor supply inputs (producing 340 VDC) (Section 2.1.2.)</li> <li>• Line driver square wave quadrature encoder input for position and velocity feedback (Section 2.3.1.)</li> <li>• Absolute Encoder support on the Feedback connector (Section 2.3.1.2.)</li> <li>• One fail-safe brake output (Section 2.3.6.)</li> <li>• Two STO sense inputs (Section 2.4.)</li> <li>• Line driver square wave auxiliary quadrature encoder input or output for PSO (Section 2.5.1.)</li> <li>• Absolute Encoder support on the Auxiliary I/O connector (Section 2.5.1.2.)</li> <li>• Four digital user outputs (Section 2.5.3.)</li> <li>• Six digital user inputs               <ul style="list-style-type: none"> <li>▪ Four Digital Inputs (Section 2.5.4.)</li> <li>▪ Two High-Speed Inputs (Section 2.5.5.)</li> </ul> </li> <li>• One 16-bit analog output (<math>\pm 10</math> V) (Section 2.5.6.)</li> <li>• One 16-bit differential analog input (<math>\pm 10</math> V) (Section 2.5.7.)</li> <li>• One 10/100/1000 BASE-T Ethernet Port (<b>iXC4 Only</b>)</li> <li>• One USB 2.0 Type C Port (<b>iXC4 Only</b>)</li> <li>• Two 10/100/1000 BASE-T Industrial Ethernet Ports (<b>iXC4 Only</b>)</li> </ul>	
Options	
Peak Current (Section 1.1.)	
-10	10 A Peak, 5 A Continuous Current
-20	20 A Peak, 10 A Continuous Current
-30	30 A Peak, 10 A Continuous Current
Expansion Board (Chapter 3)	
-EB0	No expansion board
-EB1	I/O expansion board <ul style="list-style-type: none"> <li>• Three 16-bit analog outputs (<math>\pm 10</math> V)</li> <li>• Three 16-bit differential analog inputs (<math>\pm 10</math> V)</li> <li>• 16 digital logic inputs (5 - 24 VDC), may be connected to current sourcing or sinking devices</li> <li>• 16 digital logic outputs (5 - 24 VDC), user defined as current sourcing or sinking</li> <li>• Digital logic laser firing (PSO) output</li> </ul>
Multiplier (Section 2.3.1.3.)	
-MX0	No encoder multiplier
-MX1	Interpolation circuit allowing for analog sine wave input on the primary encoder channel with an interpolation factor of 16,384.
PSO (Section 2.5.2.)	
-PSO1	One-axis PSO firing (includes One-axis Part-Speed PSO)
External Shunt (Section 2.8.)	
-SX0	No connector for the External Shunt
-SX1	Connection provided for an external shunt resistor network
Version	
-DEFAULT	Firmware Matches Software Line
-LEGACY	Legacy Firmware Version X.XX.XXX

The block diagram that follows shows a summary of the connector signals.

**Figure 1-3: Functional Diagram**



## 1.1. Electrical Specifications

**Table 1-2: Electrical Specifications**

Description		-10 Option	-20 Option	-30 Option
Motor Supply	Input Voltage	0-240 VAC		
	Input Frequency	50-60 Hz		
	Inrush Current	34 A <sub>pk</sub> @ 240 V		
	Maximum Continuous Input Current	5 A <sub>rms</sub>	10 A <sub>rms</sub>	10 A <sub>rms</sub>
	Input Current	Refer to <a href="#">Section 1.1.1. System Power Requirements</a>		
Control Supply	Input Voltage	100-240 VAC		
	Input Frequency	50-60 Hz		
	Inrush Current	68 A <sub>pk</sub> @ 240 V		
	Input Power	10 W		
Output Voltage <sup>(1)</sup>		340 VDC		
Peak Output Current (1 second) <sup>(3)</sup>		10 A	20 A	30 A
Continuous Output Current <sup>(3)</sup>		5 A	10 A	10 A
Power Amplifier Bandwidth		2500 Hz maximum (software selectable)		
Power Amplifier Efficiency		85% - 95% <sup>(2)</sup>		
PWM Switching Frequency		20 kHz		
Minimum Load Inductance		0.1 mH @ 160 VDC (1 mH @ 320 VDC)		
User Power Supply Output		5 VDC (@ 500 mA)		
Modes of Operation		Brushless; Brush; Stepper		
Protective Features		Output short circuit; Peak over current; DC bus over voltage; RMS over current; Over temperature; Control power supply under voltage; Power stage bias supply under voltage		
Isolation		Optical and transformer isolation between control and power stages.		
(1) AC input voltage and load dependent.				
(2) Dependent on total output power: efficiency increases with increasing output power.				
(3) Current is measured as the peak amplitude in any motor phase				

### 1.1.1. System Power Requirements

The following equations can be used to determine total system power requirements. The actual power required from the mains supply will be the combination of actual motor power (work), motor resistance losses, and efficiency losses in the power electronics or power transformer.

Use an EfficiencyFactor of approximately 90% in the following equations.

#### Brushless Motor

Output Power

Rotary Motors                      Power Output [W] = Torque [N·m] \* Angular velocity[rad/sec]

Linear Motors                      Power Output [W] = Force [N] \* Linear velocity[m/sec]

Rotary or Linear Motors      Power Output [W] = Bemf [V] \* I(rms) \* 3

Power Loss =  $3 * I(\text{rms})^2 * R(\text{line-line})/2$

Power Input = (Power Output + Power Loss) / EfficiencyFactor

#### DC Brush Motor

Power Output [W] = Torque [N·m] \* Angular velocity[rad/sec]

Power Loss =  $I(\text{rms})^2 * R$

Power Input = (Pout + Ploss) / EfficiencyFactor

## 1.2. Mechanical Specifications

### 1.2.1. Mounting and Cooling

Install the drive in an IP54 compliant enclosure to comply with safety standards. Make sure that there is sufficient clearance surrounding the drive for free airflow and for the cables and connections.



**IMPORTANT:** The amount of airflow required to keep the drive temperature within a sufficient range is dependent on the operating conditions. You could be required to supply additional airflow to the drive.

**Table 1-3: Mounting Specifications**


		iXC4/XC4
Customer-Supplied Enclosure		IP54 Compliant
Weight		~2.36 kg
Mounting Hardware		M4 [#8] screws (four locations, not included)
Mounting Orientation		Vertical (typical)
Dimensions		Refer to <a href="#">Section 1.2.2. Dimensions</a>
Minimum Clearance	Airflow	~25 mm
	Connectors	~100 mm
Operating Temperature		Refer to <a href="#">Section 1.3. Environmental Specifications</a>

### 1.2.2. Dimensions



**IMPORTANT:** iXC4 and XC4 dimensions are the same. iXC4 is shown.


Figure 1-4: Dimensions





**IMPORTANT:** iXC4-EB1 and XC4-EB1 dimensions are the same. iXC4-EB1 is shown.

**Figure 1-5: Dimensions [-EB1]**



### 1.3. Environmental Specifications

The environmental specifications are listed below.

**Table 1-4: Environmental Specifications**

<b>Ambient Temperature</b>	Operating: 0° to 40°C (32° to 104° F)
	Storage: -30° to 85°C (-22° to 185° F)
<b>Humidity Non-condensing</b>	The maximum relative humidity is 80% for temperatures that are less than 31°C and decreases linearly to 50% relative humidity at 40°C.
<b>Operating Altitude</b>	0 m to 2,000 m (0 ft to 6,562 ft) above sea level. If you must operate this product above 2,000 m or below sea level, contact Aerotech, Inc.
<b>Pollution</b>	Pollution Degree 2 Typically only nonconductive pollution occurs.
<b>Operation</b>	Use only indoors

## 1.4. Drive and Software Compatibility

This table shows the available drives and which version of the software first supported each drive. In the **Last Software Version** column, drives that show a specific version number are not supported after that version.

**Table 1-5: Drive and Software Compatibility**

Drive Type	Software	First Software Version	Last Software Version
iXC4	Automation1	2.0.0	Current
XC4	Automation1	1.2.0	Current
	A3200	6.04	Current

*This page intentionally left blank.*

## Chapter 2: Installation and Configuration

The sections in this chapter include details on how to set up the electrical and safety components of your system. Obey all safety warnings, including those in [Safety Procedures and Warnings](#).

### 2.1. Input Power Connections

The drive has two AC input power connectors. One connector is for control power and the other connector is for motor power. For a full list of electrical specifications, refer to [Section 1.1](#). Refer to [Section 2.11](#) for a System Interconnection Drawing.

#### 2.1.1. Control Supply Connector


The Control Supply input supplies power to the communications and logic circuitry of the drive. The **L** input is connected to an internal fuse. Refer to [Table 5-4](#) for the internal fuse value and part number. The **N** input is not connected to an internal fuse. An external fuse will be required if **N** is not connected to Neutral.

The Control Supply contains an internal filter but you could be required to add an external filter for CE compliance. Install the external filter as close as possible to the drive. Use a Schaffner FN2080 filter, an Aerotech UFM-ST noise filter module, or equivalent device.



**IMPORTANT:** Refer to local electrical safety requirements to correctly size external system wires.

**Figure 2-1: Control Supply Connections**



**Table 2-1: Control Supply Wiring Specifications**

Pin	Description	Recommended Wire Size
L	Line (L): 100-240 VAC Control Power Input	0.8 mm <sup>2</sup> (#18 AWG)
N	Neutral (N) or 100-240 VAC Control Power Input with external fuse	0.8 mm <sup>2</sup> (#18 AWG)
	Protective Ground	0.8 mm <sup>2</sup> (#18 AWG)

**Table 2-2: Mating Connector Part Numbers for the Control Supply Connector**

Type	Aerotech P/N	Third Party P/N	Screw Torque: N·m	Wire Size: mm <sup>2</sup> [AWG]
3-Pin Terminal Block	ECK02388	Phoenix 1756272	0.22 - 0.25	2.5 - 0.05 [14-30]

### 2.1.2. Motor Supply Connector

Motor power is applied to the **AC1** and **AC2** terminals of the Motor Supply connector.

Peak Current Option -10: The **AC1** input is internally connected to a 5 A fuse.

Peak Current Option -20 and -30: The **AC1** input is internally connected to a 10 A fuse.

Refer to [Table 5-4](#) for the internal fuse part numbers.

The **AC2** input is not internally fused. An external fuse is required if **AC2** is not connected to Neutral.




**IMPORTANT:** Before you operate the iXC4/XC4, install a ground connection for your safety and to prevent damage to the equipment.

For CE compliance, Aerotech recommends that you use an AC line filter. Connect the filter as close as possible to the drive. For more information about the AC line filter, refer to [Section 2.1.4](#).



**IMPORTANT:** Refer to local electrical safety requirements to correctly size external system wires.

**Figure 2-2: Motor Supply Connections**



**Table 2-3: Motor Supply Connector Wiring Specifications**

Pin	Description	Recommended Wire Size
AC1	0-240 VAC Motor Power Input	1.3 mm <sup>2</sup> (#16 AWG)
AC2	Neutral (N) or 240 VAC Motor Power Input with external fuse	1.3 mm <sup>2</sup> (#16 AWG)
	Protective Ground	1.3 mm <sup>2</sup> (#16 AWG)

**Table 2-4: Mating Connector Part Numbers for the Motor Supply Connector**

Type	Aerotech P/N	Third Part P/N	Screw Torque: Nm	Wire Size: mm <sup>2</sup> [AWG]
7-Pin Terminal Block	ECK02387	Phoenix 1756353	0.5 - 0.6	3.3 - 0.0516 [12-30]

### 2.1.3. Transformer Options

You can connect an external isolation transformer to the Motor Supply AC Input to reduce the operating voltage of the motor. Using a transformer can also reduce electrical noise.


**Table 2-5: Nominal Motor Operating Voltages / Required AC Voltages**

AC Voltage	DC Voltage
28	40
56	80
115	160
230	320

**Table 2-6: Transformer Options**

Transformer	Description
TV0.3-28-56-ST	Generate 28 or 56 VAC from 115 VAC or 230 VAC input source voltage. When rectified by the drive, it produces a 40 or 80 VDC power bus.
TM3	Power up to 4 drives, providing 300 watts of power
TM5	Power up to 4 drives providing 500 watts of power
TV0.3-28	Generate 28 VAC from 115 VAC or 230 VAC input source voltage. When rectified by the drive, it produces a 40 VDC power bus.
TV0.3-56	Generate 56 VAC from 115 VAC or 230 VAC input source voltage. When rectified by the drive, it produces an 80 VDC power bus.
TV1.5, TV2.5, or TV5	1.5 kVA, 2.5 kVA, or 5 kVA isolation transformer; 115/230 VAC input; 28, 43, 56, 70, 115 VAC output

Figure 2-3: TV0.3-28-56-ST Transformer Control and Motor Power Wiring (40 VDC Bus)




**HAZARDOUS VOLTAGES PRESENT**      **CONNECT ALL WIRING BEFORE POWERING TRANSFORMER**      **FOLLOW ALL APPLICABLE WIRING AND SAFETY CODES.**

1. For 100 VAC primary input, parallel the 100 VAC taps and leave the 115 VAC taps unterminated.
2. For 200 VAC primary input, series the 100 VAC taps and leave the 115 VAC taps unterminated.
3. When using an isolation transformer, earth grounding of the AC2 input tap reduces electrical and audible noise emissions and provides increased servo performance.
4. Transformer Primary Wiring: 0.8 mm<sup>2</sup> (#18 AWG) 300 V wire.
5. Transformer Secondary Wiring: 1.3 mm<sup>2</sup> (#16 AWG) 300 V wire.
6. AC line filters are for CE compliance. Filters may also be located on the primary side of the transformer.


Drawing: 620B1346-8, Rev. -

Figure 2-4: TV0.3-28-56-ST Transformer Control and Motor Power Wiring (80 VDC Bus)




- HAZARDOUS VOLTAGES PRESENT**      **CONNECT ALL WIRING BEFORE POWERING TRANSFORMER**      **FOLLOW ALL APPLICABLE WIRING AND SAFETY CODES.**
1. For 100 VAC primary input, parallel the 100 VAC taps and leave the 115 VAC taps unterminated.
  2. For 200 VAC primary input, series the 100 VAC taps and leave the 115 VAC taps unterminated.
  3. When using an isolation transformer, earth grounding of the AC2 input tap reduces electrical and audible noise emissions and provides increased servo performance.
  4. Transformer Primary Wiring: 0.8 mm<sup>2</sup> (#18 AWG) 300 V wire.
  5. Transformer Secondary Wiring: 1.3 mm<sup>2</sup> (#16 AWG) 300 V wire.
  6. AC line filters are for CE compliance. Filters may also be located on the primary side of the transformer.
- Drawing: 620B1346-9, Rev. -

Figure 2-5: TV0.3-28-56-ST Transformer Control and Motor Power Wiring (160 VDC Bus)



**Figure 2-6: TV0.3-28 Transformer Control and Motor Power Wiring (40 VDC Bus)**



**Figure 2-7: TV0.3-56 Transformer Control and Motor Power Wiring (80 VDC Bus)**





Figure 2-8: TM3/TM5 Transformer Control and Motor Power Wiring



-  HAZARDOUS VOLTAGES PRESENT
-  CONNECT ALL WIRING BEFORE POWERING TRANSFORMER
-  FOLLOW ALL APPLICABLE WIRING AND SAFETY CODES.

1. See the TM3 or TM5 manual for input voltage configuration
2. Wiring Specifications: 1.3 mm<sup>2</sup> (#16 AWG) 300 V wire.
3. Control Supply output voltage (115 VAC in this example) is always the same as the AC Input Voltage to the unit.

### 2.1.4. Minimizing Noise for EMC/CE Compliance



**IMPORTANT:** The iXC4/XC4 is a component designed to be integrated with other electronics. EMC testing must be conducted on the final product configuration.

To reduce electrical noise, observe the following motor feedback and input power wiring techniques.

1. Use shielded cable for motor and feedback connectors. Connect the shield to the backshell at each end of the cable.
2. Separate motor and power wiring from encoder and I/O wiring.
3. Mount drives, power supplies, and filter components on a conductive panel. Mount line filters close to the drive to keep the wire length between the drive and filter to a minimum. Use a line filter, such as Aerotech's UFM-ST, on the Motor Supply and Control Supply AC inputs.
4. Use the lowest motor voltage required by the application to reduce radiated emission.
5. Use an isolation transformer with grounded secondary to keep the effects of high frequency PWM amplifier currents to a minimum.
6. Use a separate wire for each ground connection to the drive. Use the shortest possible wire length.

The following additional changes could be required for EMC compliance and are recommended during initial EMC system evaluation.

1. Add a clamp-on ferrite to the feedback cable close to the drive.  
[Aerotech PN ECZ02348, Fair-rite PN 0446167281]
2. Add a clamp-on ferrite to the Motor Supply and Control Supply wires, including the ground wire, close to the drive.  
[Aerotech PN ECZ02347, Fair-rite PN 0446164281]
3. Add a ferrite core to the UFM-ST AC input wires. Wrap the AC wires and ground wire around the core one time.  
[Ferrite core: Aerotech PN ECZ02350, Fair-rite PN 2646102002]
4. Add a ferrite core to the motor phase and ground wires close to the drive. Wrap all four wires around the ferrite core once. Remove ferrite beads from Aerotech supplied cables if installed.  
[Ferrite core: Aerotech PN ECZ02349, Fair-rite PN 2646626402]
5. Install a motor filter module MFM10-1 close to the drive. The ferrite core that you added to the motor phase and ground wires should be located between the drive and the MFM10-1.

## 2.2. Motor Power Output Connector



**DANGER:** Before you do maintenance to the equipment, disconnect the electrical power. Wait at least ten (10) minutes after removing the power supply before doing maintenance or an inspection. Otherwise, there is the danger of electric shock.

The drive can be used to drive the following motor types:

- Brushless (refer to [Section 2.2.1.](#))
- DC Brush (refer to [Section 2.2.2.](#))
- Stepper (refer to [Section 2.2.3.](#))


For a complete list of electrical specifications, refer to [Section 1.1.](#)



**IMPORTANT:** Refer to local electrical safety requirements to correctly size external system wires.

The 7-pin terminal block style motor output connector is located on the front panel. The pinout for this connector is shown in [Table 2-7.](#)

**Table 2-7: Motor Power Output Connector Pinout**

Pin	Description	Recommended Wire Size	Connector
	Earth Ground to Motor	1.3 mm <sup>2</sup> (#16 AWG)	
A	Brushless Phase A Motor Lead DC Brush + Stepper	1.3 mm <sup>2</sup> (#16 AWG)	
B	Brushless Phase B Motor Lead Stepper	1.3 mm <sup>2</sup> (#16 AWG)	
C	Brushless Phase C Motor Lead DC Brush - Stepper Return	1.3 mm <sup>2</sup> (#16 AWG)	


**Table 2-8: Mating Connector Part Numbers for the Motor Power Output Connector**

Type	Aerotech P/N	Third Part P/N	Screw Torque: Nm	Wire Size: mm <sup>2</sup> [AWG]
7-Pin Terminal Block	ECK02387	Phoenix 1756353	0.5 - 0.6	3.3 - 0.0516 [12-30]

### 2.2.1. Brushless Motor Connections

The configuration in [Figure 2-9](#) shows a typical brushless motor connection.

**Figure 2-9: Brushless Motor Configuration**



**Table 2-9: Wire Colors for Aerotech-Supplied Brushless Motor Cables**

Pin	Wire Color Set 1 <sup>(1)</sup>	Wire Color Set 2	Wire Color Set 3	Wire Color Set 4
⊕	Green/Yellow & Shield <sup>(2)</sup>	Green/Yellow & Shield	Green/Yellow & Shield	Green/Yellow & Shield
A	Black	Blue & Yellow	Black #1	Black & Brown
B	Red	Red & Orange	Black #2	Red & Orange
C	White	White & Brown	Black #3	Violet & Blue

(1) Wire Color Set #1 is the wire set typically used by Aerotech.  
 (2) "&" indicates two wires (Red & Orange); "/" indicates a single wire (Green/White).

Brushless motors are commutated electronically by the controller. The use of Hall effect devices for commutation is recommended.

The controller requires that the Back-EMF of each motor phase be aligned with the corresponding Hall-effect signal. To ensure proper alignment, motor, Hall, and encoder connections should be verified using one of the following methods: *powered*, through the use of a test program; or *unpowered* using an oscilloscope. Both methods will identify the A, B, and C Hall/motor lead sets and indicate the correct connections to the controller. Refer to [Section 2.2.1.1.](#) for powered motor phasing or [Section 2.2.1.2.](#) for unpowered motor and feedback phasing.

For Aerotech-supplied systems, the motor, encoder and Hall sensors are correctly configured and connection adjustments are not necessary.

A motor filter module can be installed between the drive and the motor to reduce the effects on PWM generated noise currents.


**2.2.1.1. Brushless Motor Powered Motor and Feedback Phasing**

Observe the state of the encoder and Hall-effect device signals in the Diagnostics section of the Status Utility.


**Table 2-10: Hall Signal Diagnostics**

Hall-Signal Status	Definition
--	0 V or logic low
ON	5 V or logic high

**Figure 2-10: Positive Motor Direction**




**Figure 2-11: Encoder and Hall Signal Diagnostics**



**2.2.1.2. Brushless Motor Unpowered Motor and Feedback Phasing**


Disconnect the motor from the controller and connect the motor in the test configuration shown in Figure 2-12. This method will require a two-channel oscilloscope, a 5V power supply, and six resistors (10,000 ohm, 1/4 watt). All measurements should be made with the probe common of each channel of the oscilloscope connected to a neutral reference test point (TP4, shown in Figure 2-12). Wave forms are shown while moving the motor in the positive direction.

**Figure 2-12: Brushless Motor Phasing Oscilloscope Example**



With the designations of the motor and Hall leads of a third party motor determined, the motor can now be connected to an Aerotech system. Connect motor lead A to motor connector A, motor lead B to motor connector B, and motor lead C to motor connector C. Hall leads should also be connected to their respective feedback connector pins (Hall A lead to the Hall A feedback pin, Hall B to Hall B, and Hall C to Hall C). The motor is correctly phased when the Hall states align with the Back EMF as shown in Figure 2-13. Use the CommutationOffset parameter to correct for Hall signal misalignment.


**Figure 2-13: Brushless Motor Phasing Goal**



### 2.2.2. DC Brush Motor Connections

The configuration shown in Figure 2-14 is an example of a typical DC brush motor connection. Refer to Section 2.2.2.1. for information on motor phasing.

**Figure 2-14: DC Brush Motor Configuration**



**Table 2-11: Wire Colors for Aerotech-Supplied DC Brush Motor Cables**

Pin	Wire Color Set 1 <sup>(1)</sup>	Wire Color Set 2	Wire Color Set 3
⊕	Green & White & Shield <sup>(2)</sup>	Green/Yellow & Shield	Green/Yellow & Shield
A	Red & Orange	Red	Red & Orange
C	Yellow & Blue	Black	Yellow & Blue


(1) Wire Color Set #1 is the typical wire set used by Aerotech.  
 (2) "&" (Red & Orange) indicates two wires; "/" (Green/White) indicates a single wire.

#### 2.2.2.1. DC Brush Motor Phasing

A properly phased motor means that the positive motor lead should be connected to the ØA motor terminal and the negative motor lead should be connected to the ØC motor terminal. To determine if the motor is properly phased, connect a voltmeter to the motor leads of an un-powered motor:

1. Connect the positive lead of the voltmeter to the one of the motor terminals.
2. Connect the negative lead of the voltmeter to the other motor terminal.
3. Move or rotate the motor in the positive or clockwise (CW) direction by hand.

**Figure 2-15: Positive Motor Direction**



4. If the voltmeter indicates a negative value, swap the motor leads and move the motor by hand in the positive direction, again. When the voltmeter indicates a positive value, the motor leads have been identified.
5. Connect the motor lead from the positive lead of the voltmeter to the ØA motor terminal on the drive. Connect the motor lead from the negative lead of the voltmeter to the ØC motor terminal on the drive.


For Aerotech-supplied systems, the motor, encoder and Hall sensors are correctly configured and connection adjustments are not necessary.

### 2.2.3. Stepper Motor Connections

The configuration shown in Figure 2-16 is an example of a typical stepper motor connection. Refer to Section 2.2.3.1. for information on motor phasing.

In this case, the effective motor voltage is half of the applied bus voltage. For example, an 80 V motor bus supply is needed to get 40 V across the motor.

**Figure 2-16: Stepper Motor Configuration**



**Table 2-12: Wire Colors for Aerotech-Supplied Stepper Motor Cables**

Pin	Wire Color Set 1 <sup>(1)</sup>	Wire Color Set 2
⊕	Green/Yellow & Shield <sup>(2)</sup>	Green/Yellow & Shield
A	Black	Brown
B	Red	Yellow
C	White	White & Red

(1) Wire Color Set #1 is the typical wire set used by Aerotech.  
 (2) "&" (Red & Orange) indicates two wires; "/" (Green/White) indicates a single wire.

#### 2.2.3.1. Stepper Motor Phasing


A stepper motor can be run with or without an encoder.

**Without an Encoder:** You do not need to phase the motor.

**With an Encoder:** Because the end of travel (EOT) limit inputs are relative to motor rotation, it is important to phase the motor.

Run a positive motion command. The motor is phased correctly if there is a positive scaling factor (determined by the ServoLoopSetup parameter) and the motor moves in a clockwise direction when you view the motor from the front mounting flange (Figure 2-17). If the motor moves in a counterclockwise direction, reverse the motor leads and re-run the command. After the motor has been phased, if you want to change the direction of positive motion, use the ReverseMotionDirection parameter.

**Figure 2-17: Positive Motor Direction**



For Aerotech-supplied systems, the motor, encoder and Hall sensors are correctly configured and connection adjustments are not necessary.


### 2.2.4. Three Phase Stepper Motor Connections



**IMPORTANT:** This feature is only supported in Automation1 software version 2.2.0. or later.

The configuration shown in [Figure 2-18](#) is an example of a typical three phase stepper motor connection. Refer to [Section 2.2.4.1.](#) for information on motor phasing.

**Figure 2-18: Three Phase Stepper Motor Configuration**



#### 2.2.4.1. Stepper Motor Phasing


A three phase stepper motor can be run with or without an encoder.

**Without an Encoder:** You do not need to phase the motor.

**With an Encoder:** Because the end of travel (EOT) limit inputs are relative to motor rotation, it is important to phase the motor.

Run a positive motion command. The motor is phased correctly if there is a positive scaling factor (determined by the ServoLoopSetup parameter) and the motor moves in a clockwise direction when you view the motor from the front mounting flange ([Figure 2-19](#)). If the motor moves in a counterclockwise direction, reverse the motor leads and re-run the command. After the motor has been phased, if you want to change the direction of positive motion, use the ReverseMotionDirection parameter.


**Figure 2-19: Positive Motor Direction**



## 2.3. Feedback Connector

The connector pin assignment is shown in [Table 2-13](#) with detailed connection information in the following sections.

**Table 2-13: Feedback Connector Pinout**

Pin #	Description	In/Out/Bi	Connector
1	Reserved	N/A	
2	Motor Over Temperature Thermistor	Input	
3	+5V Power <sup>(1)</sup>	Output	
4	Plug and Play Serial Data (for Aerotech stages only)	Bidirectional	
5	Hall-Effect Sensor B (brushless motors only)	Input	
6	Encoder Marker Reference Pulse -	Input	
	Absolute Encoder Clock -	Output	
7	Encoder Marker Reference Pulse +	Input	
	Absolute Encoder Clock +	Output	
8	Absolute Encoder Data -	Bidirectional	
9	Reserved	N/A	
10	Hall-Effect Sensor A (brushless motors only)	Input	
11	Hall-Effect Sensor C (brushless motors only)	Input	
12	Clockwise End of Travel Limit	Input	
13	Brake Output -	Output	
14	Encoder Cosine +	Input	
15	Encoder Cosine -	Input	
16	+5V Power <sup>(1)</sup>	Output	
17	Encoder Sine +	Input	
18	Encoder Sine -	Input	
19	Absolute Encoder Data+	Bidirectional	
20	Signal Common	Output	
21	Signal Common	Output	
22	Home Switch Input	Input	
23	Encoder Fault Input	Input	
24	Counterclockwise End of Travel Limit	Input	
25	Brake Output +	Output	

(1) The maximum combined current output is 500 mA.

**Table 2-14: Mating Connector Part Numbers for the Feedback Connector**

Mating Connector	Aerotech P/N	Third Party P/N
25-Pin D-Connector	ECK00101	FCI DB25P064TXLF
Backshell	ECK00656	Amphenol 17E-1726-2

### 2.3.1. Primary Encoder Inputs

The primary encoder inputs are accessible through the Feedback connector. Use the PrimaryFeedbackType [A3200: PositionFeedbackType or VelocityFeedbackType] parameter to configure the drive to accept an encoder signal type.

Square Wave encoder signals: [Section 2.3.1.1.](#)

Absolute encoder signals: [Section 2.3.1.2.](#)

Sine Wave encoder signals (as permitted by the multiplier option): [Section 2.3.1.3.](#)

You cannot use a sine wave encoder with the -MX1 multiplier option as an input to the PSO. The -MX1 option does not generate emulated quadrature signals.

Refer to [Section 2.3.1.4.](#) for encoder feedback phasing.

Refer to [Section 2.5.](#) for the auxiliary encoder input on the Aux I/O connector.

**Table 2-15: Multiplier Options**

Option	Primary Encoder Accepts...	Auxiliary Encoder Accepts...
-MX0	Square Wave or Absolute encoders	Square Wave or Absolute encoders
-MX1	Sine Wave, Square Wave, or Absolute encoders	Square Wave or Absolute encoders



**IMPORTANT:** Physically isolate the encoder wiring from motor, AC power, and all other power wiring

**Table 2-16: Primary Encoder Input Pins on the Feedback Connector**

Pin #	Description	In/Out/Bi
3	+5V Power <sup>(1)</sup>	Output
6	Encoder Marker Reference Pulse -	Input
	Absolute Encoder Clock -	Output
7	Encoder Marker Reference Pulse +	Input
	Absolute Encoder Clock +	Output
8	Absolute Encoder Data -	Bidirectional
14	Encoder Cosine +	Input
15	Encoder Cosine -	Input
16	+5V Power <sup>(1)</sup>	Output
17	Encoder Sine +	Input
18	Encoder Sine -	Input
19	Absolute Encoder Data+	Bidirectional
20	Signal Common	Output
21	Signal Common	Output

(1) The maximum combined current output is 500 mA.


**2.3.1.1. Square Wave Encoder (Primary)**

The drive accepts RS-422 square wave encoder signals. The drive will generate a feedback fault if it detects an invalid signal state caused by an open or shorted signal connection. Use twisted-pair wiring for the highest performance and noise immunity.

**Table 2-17: Square Wave Encoder Specifications**

Specification	Value
Encoder Frequency	10 MHz maximum (25 ns minimum edge separation)
x4 Quadrature Decoding	40 million counts/sec

**Figure 2-20: Square Wave Encoder Schematic (Feedback Connector)**




### 2.3.1.2. Absolute Encoder (Primary)

The drive retrieves absolute position data along with encoder fault information through a serial data stream from the absolute encoder. Use twisted-pair wiring for the highest performance and noise immunity. You cannot echo an absolute encoder signal.

Refer to [Figure 2-21](#) for the serial data stream interface.

Refer to the [Help file](#) for information on how to set up your EnDat or BiSS absolute encoder parameters.

**Figure 2-21: Absolute Encoder Schematic (Feedback Connector)**



### 2.3.1.3. Sine Wave Encoder (Primary) [-MX1 Option]

The Sine Wave Encoder option provides higher positioning resolution by subdividing the fundamental output period of the encoder into smaller increments. The amount of subdivision is specified by the [PrimaryEncoderMultiplicationFactor](#) [A3200: EncoderMultiplicationFactor] parameter. Use Encoder Tuning [A3200: Feedback Tuning] to adjust the value of the gain, offset, and phase balance controller parameters to get the best performance. For more information, refer to the [Help file](#).

High resolution or high-speed encoders can require increased bandwidth for correct operation. Use the High Speed Mode of the [PrimaryEncoderMultiplierSetup](#) [A3200: EncoderMultiplierSetup] parameter to enable the high bandwidth mode. Because this mode increases sensitivity to system noise, use it only if necessary.


You cannot use a sine wave encoder with the -MX1 multiplier option as an input to the PSO. The -MX1 option does not generate emulated quadrature signals.

For the highest performance, use twisted pair double-shielded cable with the inner shield connected to signal common and the outer shield connected to frame ground. Do not join the inner and outer shields in the cable.


**Table 2-18: Sine Wave Encoder Specifications**

Specification	Value
Input Frequency (max)	450 kHz, 2 MHz
Input Amplitude <sup>(1)</sup>	0.6 to 1.75 V <sub>pk-pk</sub>
Interpolation Factor (max)	16,384
Input Common Mode	1.5 to 3.5 VDC
<small>(1) Measured as SIN(+) - SIN(-) or COS(+) - COS(-)</small>	

**Figure 2-22: Sine Wave Encoder Phasing Reference Diagram**



**Figure 2-23: Sine Wave Encoder Schematic (Feedback Connector)**




**2.3.1.4. Encoder Phasing**

Incorrect encoder polarity will cause the system to fault when enabled or when a move command is issued. Figure 2-24 illustrates the proper encoder phasing for clockwise motor rotation (or positive forcer movement for linear motors). To verify, move the motor by hand in the CW (positive) direction while observing the position of the encoder in the diagnostics display (see Figure 2-25).


For dual loop systems, the velocity feedback encoder is displayed in the diagnostic display (Figure 2-25).

**Figure 2-24: Encoder Phasing Reference Diagram (Standard)**



**IMPORTANT:** Encoder manufacturers may refer to the encoder signals as A, B, and Z. The proper phase relationship between signals is shown in Figure 2-24.

**Figure 2-25: Position Feedback in the Diagnostic Display**



### 2.3.2. Hall-Effect Inputs

The Hall-effect switch inputs are recommended for AC brushless motor commutation but not absolutely required. The Hall-effect inputs accept 5 VDC level signals. Hall states (0,0,0) or (1,1,1) are invalid and will generate a "Hall Fault" axis fault.


Refer to [Section 2.2.1.1](#), for Hall-effect device phasing.

**Table 2-19: Hall-Effect Feedback Pins on the Feedback Connector**

Pin #	Description	In/Out/Bi
3	+5V Power <sup>(1)</sup>	Output
5	Hall-Effect Sensor B (brushless motors only)	Input
10	Hall-Effect Sensor A (brushless motors only)	Input
11	Hall-Effect Sensor C (brushless motors only)	Input
16	+5V Power <sup>(1)</sup>	Output
20	Signal Common	Output
21	Signal Common	Output

(1) The maximum combined current output is 500 mA.

**Figure 2-26: Hall-Effect Inputs Schematic (Feedback Connector)**



### 2.3.3. Thermistor Input


The thermistor input is used to detect a motor over temperature condition by using a positive temperature coefficient sensor. As the temperature of the sensor increases, so does the resistance. Under normal operating conditions, the resistance of the thermistor is low which will result in a low input signal. As the increasing temperature causes the resistance of the thermistor to increase, the sensor will trigger an over temperature fault.

The thermistor is connected between Pin 2 and Signal Common. The nominal trip value of the sensor is 1.385 k $\Omega$ . The circuit includes a 12 k $\Omega$  internal pull-up resistor which corresponds to a trip voltage of +0.52 V.

**Table 2-20: Thermistor Input Pin on the Feedback Connector**

Pin #	Description	In/Out/Bi
2	Motor Over Temperature Thermistor	Input

**Figure 2-27: Thermistor Input Schematic (Feedback Connector)**




### 2.3.4. Encoder Fault Input

The encoder fault input is for use with encoders that have a fault output. This is provided by some manufacturers and indicates a loss of encoder function. The active state of this input is parameter configurable and the controller should be configured to disable the axis when the fault level is active. The nominal trip voltage of the encoder fault input is +2.5 V.

**Table 2-21: Encoder Fault Input Pin on the Feedback Connector**

Pin #	Description	In/Out/Bi
23	Encoder Fault Input	Input

**Figure 2-28: Encoder Fault Input Schematic (Feedback Connector)**



### 2.3.5. End of Travel and Home Limit Inputs

End of Travel (EOT) limits are required to define the end of the physical travel on linear axes. Positive or clockwise motion is stopped by the clockwise (CW) end of travel limit input. Negative or counterclockwise motion is stopped by the counterclockwise (CCW) end of travel limit input. The Home Limit switch can be parameter configured for use during the home cycle, however, the CW or CCW EOT limit is typically used instead. All of the end-of-travel limit inputs accept 0-24 VDC level signals. Limit directions are relative to the encoder polarity in the diagnostics display (refer to [Figure 2-31](#)).

**Table 2-22: End of Travel and Home Limit Pins on the Feedback Connector**

Pin #	Description	In/Out/Bi
12	Clockwise End of Travel Limit	Input
16	+5V Power	Output
20	Signal Common	Output
21	Signal Common	Output
22	Home Switch Input	Input
24	Counterclockwise End of Travel Limit	Input

The active state (High/Low) of the EOT limits is software selectable (by the EndOfTravelLimitSetup axis parameter). [Figure 2-29](#) shows the possible wiring configurations for normally-open and normally-closed switches and the parameter setting to use for each configuration.



**IMPORTANT:** Use NPN-type normally-closed limit switches (Active High) to provide fail-safe behavior in the event of an open circuit.

Figure 2-29: End of Travel and Home Limit Input Connections






Figure 2-30: End of Travel and Home Limit Input Schematic (Feedback Connector)



**2.3.5.1. End of Travel and Home Limit Phasing**

If the EOT limits are reversed, you will be able to move further into a limit but be unable to move out. To correct this, swap the connections to the CW and CCW inputs at the Feedback connector or swap the CW and CCW limit functionality in the software using the EndOfTravelLimitSetup parameter. View the logic level of the EOT limit inputs in the Diagnostics display (shown in [Figure 2-31](#)).

**Figure 2-31: End of Travel and Home Limit Input Diagnostic Display**



### 2.3.6. Brake Outputs

The drive has a dedicated brake control circuit. Configure the brake with the BrakeSetup [A3200: EnableBrakeControl] parameter for automatic control (typical). You can also use software commands to directly control the brake output.

Refer to [Section 2.6](#) for more information on powering the brake circuit.

**Table 2-23: Brake Output Pins on the Feedback Connector**


Pin #	Description	In/Out/Bi
13	Brake Output -	Output
25	Brake Output +	Output

**Table 2-24: Brake Control Specifications**

Specification	Value
Maximum Voltage	24 VDC
Maximum Current	1 A

A varistor must be connected across the brake to minimize voltage transients.

**Figure 2-32: Brake Connected to the 25-Pin Feedback Connector (Typical)**



## 2.4. Safe Torque Off Input (STO)



**IMPORTANT:** iXC4 certification is pending.

The STO circuit is comprised of two identical channels, each of which must be energized in order for the drive to produce motion. Each STO input is opto-isolated and accepts 24 V levels directly without the need for external current limiting resistors.



**IMPORTANT:** The drive might be equipped with an STO bypass circuit board. The bypass circuit board defeats the STO safety circuit and allows the system to run at all times. To use the STO safety functionality, remove the circuit board and make connections as outlined in this section.



**IMPORTANT:** The application circuit and its suitability for the desired safety level is the sole responsibility of the user of the drive.



**WARNING:** STO wires must be insulated to prevent short circuits between connector pins. The primary concern is a short circuit between STO 1 IN and STO 2 IN wire strands.

**Table 2-25: STO Connector Pinout**

Pin #	Signal	Description	In/Out/Bi	Connector
1	Power Supply +	Use only to defeat STO by connecting to STO 1 IN and STO 2 IN. Not for customer use.	Output	
2	STO 1 IN	STO Channel 1 Positive Input	Input	
3	RETURN	STO Negative Input	Input	
4	STO 2 IN	STO Channel 2 Positive Input	Input	
5	Power Supply -	Use only to defeat STO by connecting to RETURN. Not for customer use.	Output	

**Table 2-26: Mating Connector Part Numbers for the STO Connector**

Description	Aerotech P/N	Phoenix P/N	Tightening Torque (Nm)	Wire Size: AWG [mm <sup>2</sup> ]
5-Pin Terminal Block	ECK02393	1827622	0.22 - 0.25	2.5 - 0.05 [14-30]

**Table 2-27: STO Electrical Specifications**


Status	Value
STO off (motion allowed)	18-24 V, 7 ma
STO on (safe state entered, no motion)	0-6 V
Recommended Wire Gauge	22-26 AWG (0.5 - 0.14 mm <sup>2</sup> )
STO System Power Supply	PELV
STO Wire Length (maximum)	50 m

Figure 2-33 shows one safety device connected to multiple drives in parallel.



**WARNING:** The drive does not check for short circuits on the external STO wiring. If this is not done by the external safety device, short circuits on the wiring must be excluded. Refer to EN ISO 13849-2. For Category 4 systems, the exclusion of short circuits is mandatory.

**Figure 2-33: Typical STO Configuration**



### 2.4.1. STO Standards

Table 2-28 describes and specifies the safety requirements at the system level for the Safe Torque Off (STO) feature of the drive. This assumes that diagnostic testing is performed according to Section 2.4.4. and Table 2-29.

**Table 2-28: STO Standards**

Standard	Maximum Achievable Safety
EN/IEC 61800-5- 2:2016	SIL 3
EN/IEC 61508-1:2010	SIL 3
EN/IEC 61508-2:2010	SIL 3
EN ISO 13849-1:2015	Category 4, PL e
EN/IEC 62061:2005 with Amendments	SIL 3

**Table 2-29: STO Standards Data**

Standard	Value
EN ISO 13849-1:2015	MTTF <sub>D</sub> > 1000 years, DC <sub>AVG</sub> 99% Maximum PL e, Category 4
EN ISO 13849-1:2015 EN/IEC 61508	Lifetime = 20 years No proof test required Interval for manual STO test: <ul style="list-style-type: none"> <li>• Once per year for SIL2/PL d/category 3</li> <li>• Once per three months for SIL3/PL e/category 3</li> <li>• Once per day for SIL3/PL e/category 4</li> </ul>
EN/IEC 61508	SIL3 PFH < 3 FIT SFF > 99%

### 2.4.2. STO Functional Description

The motor can only be activated when voltage is applied to both STO 1 and STO 2 inputs. The STO state will be entered if power is removed from either the STO 1 or the STO 2 inputs. When the STO state is entered, the motor cannot generate torque or force and is therefore considered safe.

The STO function is implemented with two redundant channels in order to meet stated performance and SIL levels. STO 1 disconnects the high side power amplifier transistors and STO 2 disconnects the low side power amplifier transistors. Disconnecting either set of transistors effectively prevents the drive from being able to produce motion.

The drive software monitors each STO channel and will generate an Emergency Stop software fault when either channel signals the stop state. Each STO channel contains a fixed delay which allows the drive to perform a controlled stop before the power amplifier transistors are turned off.

A typical configuration requiring a controlled stop has the Emergency Stop Fault mask bit set in the FaultMask, FaultMaskDecel, and FaultMaskDisable parameters. This stops the axis using the rate specified by the AbortDecelRate parameter. The software will disable the axis as soon as the deceleration ramp is complete. This is typically configured to occur before the STO channel turns off the power amplifier transistors.

The software controlled stop functionality must be excluded when considering overall system safety. This is because the software is not safety rated and cannot be included as part of the safety function.

The drive will tolerate short diagnostic pulses on the STO 1+ and STO 2+ inputs. The parameter "STOPulseFilter" specifies the maximum pulse width that the drive will ignore.

To resume normal operation, apply power to both STO 1 and STO 2 inputs and use the *Acknowledge All* button or the AcknowledgeAll() or FaultAcknowledge() function to clear the Emergency Stop software fault. The recommended use of the Emergency Stop Fault fault mask bits prevent the system from automatically restarting.

You can achieve longer delay times through the use of an external delay timer, such as the Omron G9SA-321 Safety Relay Unit. Place this device between the system ESTOP wiring and the drive's STO inputs. Connect the ESTOP signal directly to a digital input, in addition to the external timer, to allow the drive to begin a software-controlled stop as soon as the ESTOP signal becomes active. Use the EmergencyStopFaultInput [A3200: ESTOPFaultInput] parameter to configure a digital input as an ESTOP input.

Non-standard STO delay times are provided by special factory order. In this case, the non-standard STO delay time is indicated by a label placed on the slice amplifier's main connector (STO DELAY = xx sec).

**Table 2-30: STO Signal Delay**

	Value
STO Time Delay	450-550 msec

**Table 2-31: Motor Function Relative to STO Input State**

STO 1	STO 2	Motor Function
Unpowered	Unpowered	No force/torque
Unpowered <sup>(1)</sup>	Powered <sup>(1)</sup>	No force/torque
Powered <sup>(1)</sup>	Unpowered <sup>(1)</sup>	No force/torque
Powered	Powered	Normal Operation

1. This is considered a Fault Condition since STO 1 and STO 2 do not match. Refer to [Section 2.4.4](#).

### 2.4.3. STO Startup Validation Testing

Verify the state of the STO 1 and STO 2 channels by manually activating the external STO hardware. Each STO channel must be tested separately in order to detect potential short circuits between the channels. The current state of the STO 1 and STO 2 inputs is shown in the Status Utility. A “-” indicates that the STO input is powered by a high voltage level (24 V). An “ON” indicates that the voltage source has been removed from the input (open circuit or 0 V), and that the STO channel is in the safe state.



**DANGER:** The STO circuit does not remove lethal voltage from the motor terminals. AC mains power must be removed before servicing.

### 2.4.4. STO Diagnostics


Activation of STO means removing power from the drive's STO inputs. This is typically done by pressing the emergency stop switch. The drive initiates a diagnostic check every time the STO is activated after the Diagnostic Test Delay Time has elapsed. The diagnostic check verifies that each channel has entered the safe state. The drive is held in the safe state if it determines that one of the channels has not properly entered the safe state. An open circuit or short to 24 V in either STO channel will result in this condition (refer to [Section 2.4.3.](#)). The Status Utility screen can be used to verify the levels of the STO input signals while trouble shooting.

In order to meet the listed SIL level, the STO circuit must be activated (power removed from both inputs) according to the interval specified in [Table 2-29.](#)

**Table 2-32: STO Timing**

Time	Description	Value
T1	STO Delay Time (STO input active to motor power off)	450-550 msec
T2	STO deactivated to motor power on (the software is typically configured so that the motor does not automatically re-energize).	< 1 msec
T3	Diagnostic Test Delay Time	550-610 msec

**Figure 2-34: STO Timing**




The software is typically configured to execute a controlled stop when the STO state is first detected. If power is reapplied to the STO inputs before the STO Delay Time, an STO hardware shutdown will not occur but a software stop may, depending on the width of the STO pulse. The controller will ignore STO active pulses shorter in length than the STOPulseFilter parameter setting.

## 2.5. Auxiliary I/O Connector

The Auxiliary I/O connector has 1 analog input, 6 digital inputs, 1 analog output, 4 digital outputs, a secondary line driver encoder input, and a secondary absolute encoder interface.

**Table 2-33: Auxiliary I/O Connector Pinout**

Pin#	Description	In/Out/Bi	Connector
1	Auxiliary Sine +	Bidirectional	
	Absolute Encoder Data +	Bidirectional	
2	Auxiliary Sine -	Bidirectional	
	Absolute Encoder Data -	Bidirectional	
3	High-Speed Input 20 + / PSO External Sync. +	Input	
4	High-Speed Input 20 - / PSO External Sync. -	Input	
5	High-Speed Input 21 +	Input	
6	High-Speed Input 21 -	Input	
7	Digital Output 0	Output	
8	Digital Output 1	Output	
9	Digital Output 2	Output	
10	Auxiliary Cosine +	Bidirectional	
	Absolute Encoder Clock +	Output	
11	Auxiliary Cosine-	Bidirectional	
	Absolute Encoder Clock -	Output	
12	+5 Volt (500 mA max)	Output	
13	Analog Input 0+ (Differential)	Input	
14	Analog Input 0- (Differential)	Input	
15	Digital Output Common	Output	
16	Digital Output 3	Output	
17	Digital Input 0 / CCW EOT Input <sup>(1)</sup>	Input	
18	Digital Input 1 / CW EOT Input <sup>(1)</sup>	Input	
19	Auxiliary Marker- / PSO output <sup>(2)</sup> / TTL Output	Bidirectional	
20	Auxiliary Marker+ / PSO output <sup>(2)</sup>	Bidirectional	
21	Common	Output	
22	Analog Output 0	Output	
23	Analog Common	Output	
24	Digital Input Common	Output	
25	Digital Input 2 / Home Input <sup>(1)</sup>	Input	
26	Digital Input 3	Input	

(1) Software configured option  
(2) For PSO, refer to [Section 2.5.2](#).

**Table 2-34: Mating Connector Part Numbers for the Auxiliary I/O Connector**

Mating Connector	Aerotech P/N	Third Party P/N
Connector	ECK01259	Kycon K86-AA-26P
Backshell	ECK01022	Amphenol 17-1725-2

NOTE: These items are provided as a set under the Aerotech P/N: MCK-26HDD.

### 2.5.1. Auxiliary Encoder Inputs

The Auxiliary Encoder connector gives you a second encoder input channel. This channel is typically used for dual loop applications.

Use the AuxiliaryFeedbackType [A3200: PositionFeedbackType or VelocityFeedbackType] parameter to configure the drive to accept an encoder signal type.

Square Wave encoder signals: [Section 2.5.1.1.](#)

Absolute encoder signals: [Section 2.5.1.2.](#)

You can configure the Auxiliary Encoder interface as an output that will transmit encoder signals for external use. Use the DriveEncoderOutputConfigureInput() function [A3200: EncoderDivider parameter] to configure the Sine  $\pm$  and Cosine  $\pm$  connector pins as RS-422 outputs. You can only echo incremental square wave primary encoder inputs. You cannot use the absolute encoder interface when you echo incremental signals.

**Table 2-35: Auxiliary Encoder Pins on the Auxiliary I/O Connector**

Pin#	Description	In/Out/Bi
1	Auxiliary Sine +	Bidirectional
	Absolute Encoder Data +	Bidirectional
2	Auxiliary Sine -	Bidirectional
	Absolute Encoder Data -	Bidirectional
10	Auxiliary Cosine +	Bidirectional
	Absolute Encoder Clock +	Output
11	Auxiliary Cosine-	Bidirectional
	Absolute Encoder Clock -	Output
12	+5 Volt (500 mA max)	Output
19	Auxiliary Marker- / PSO output <sup>(2)</sup> / TTL Output	Bidirectional
20	Auxiliary Marker+ / PSO output <sup>(2)</sup>	Bidirectional
21	Common	Output

(2) For PSO, refer to [Section 2.5.2.](#)


**2.5.1.1. Square Wave Encoder (Auxiliary)**

The drive accepts RS-422 square wave encoder signals. The drive will generate a feedback fault if it detects an invalid signal state caused by an open or shorted signal connection. Use twisted-pair wiring for the highest performance and noise immunity.

**Table 2-36: Square Wave Encoder Specifications**

Specification	Value
Encoder Frequency	10 MHz maximum (25 ns minimum edge separation)
x4 Quadrature Decoding	40 million counts/sec

**Figure 2-35: Square Wave Encoder Interface (Aux I/O Connector)**




**2.5.1.2. Absolute Encoder (Auxiliary)**

The drive retrieves absolute position data along with encoder fault information through a serial data stream from the absolute encoder. Use twisted-pair wiring for the highest performance and noise immunity. You cannot use an absolute encoder with incremental signals on the Auxiliary I/O Connector.

Refer to [Figure 2-36](#) for the serial data stream interface.

Refer to the [Help file](#) for information on how to set up your EnDat or BiSS absolute encoder parameters.

**Figure 2-36: Absolute Encoder Schematic (Auxiliary I/O Connector)**



### 2.5.2. Position Synchronized Output (PSO)

The PSO signal is available on the dual-function AUX Marker/PSO signal lines. Use the [PSO pulse external sync functions \[A3200: PSOOUTPUT PULSE EXTSYNC command\]](#) to configure the auxiliary marker as an output. Refer to the [Help file](#) for more information.

Use the `PsoOutputConfigureOutput()` function [A3200: PSOOUTPUT CONTROL command] to transmit the PSO output signal on the Marker  $\pm$  pins differentially. Or, use the `PsoOutputConfigureOutput()` function [A3200: PSOOUTPUT CONTROL command] to configure the Marker - pin as a 5V TTL PSO output.

You cannot use a sine wave encoder with the -MX1 multiplier option as an input to the PSO. The -MX1 option does not generate emulated quadrature signals.

The differential signal format is recommended when using long cable lengths in noisy environments or when high frequency pulse transmission is required. It is best to locate the line receiver close to the receiving electronics. A 5 V TTL signal is used to drive an opto coupler or general purpose TTL input. This signal is active high and is driven to 5 V when a PSO fire event occurs. When the drive is reset or after initial power up, the PSO pins (refer to [Table 2-38](#)), are not actively driven and the fail safe state is defined by pull-up and pull-down resistors as shown in [Figure 2-37](#).

The -EB1 I/O option board has additional PSO signal formats. Refer to [Section 3.5](#) for more information.


**Table 2-37: PSO Specifications**

Specification		Value
Output	TTL	5 V, 16 mA (max)
Maximum PSO Output (Fire) Frequency	TTL	12.5 MHz
	RS-422	12.5 MHz
Output Latency [Fire event to output change]	TTL	15 ns
	RS-422	15 ns

**Table 2-38: PSO Pins on the Auxiliary I/O Connector**

Pin#	Description	In/Out/Bi
19	Auxiliary Marker- / PSO output / TTL Output	Bidirectional
20	Auxiliary Marker+ / PSO output	Bidirectional
21	Common	Output

**Figure 2-37: PSO Interface**



### 2.5.3. Digital Outputs

Optically-isolated solid-state relays drive the digital outputs. You can connect the digital outputs in current sourcing or current sinking mode but you must connect all four outputs in the same configuration. Refer to [Figure 2-39](#) and [Figure 2-40](#).

You must install suppression diodes on digital outputs that drive relays or other inductive devices. To see an example of a current sourcing output that has diode suppression, refer to [Figure 2-39](#). To see an example of a current sinking output that has diode suppression, refer to [Figure 2-40](#).

The digital outputs are not designed for high-voltage isolation applications and they should only be used with ground-referenced circuits.

The digital outputs have overload protection. They will resume normal operation when the overload is removed.


**Table 2-39: Digital Output Specifications**

Digital Output Specifications	Value
Maximum Voltage	24 V (26 V Maximum)
Maximum Sink/Source Current	250 mA/output
Output Saturation Voltage	0.9 V at maximum current
Output Resistance	3.7 $\Omega$
Rise / Fall Time	250 $\mu$ s (2K pull up to 24V)
Reset State	Output Off (High Impedance State)


**Table 2-40: Digital Output Pins on the Auxiliary I/O Connector**

Pin#	Description	In/Out/Bi
7	Digital Output 0	Output
8	Digital Output 1	Output
9	Digital Output 2	Output
15	Digital Output Common	Output
16	Digital Output 3	Output

**Figure 2-38: Digital Output Schematic (Aux I/O Connector)**




**Figure 2-39: Digital Outputs Connected in Current Sourcing Mode**



 DIODE REQUIRED ON EACH OUTPUT THAT DRIVES AN INDUCTIVE DEVICE (COIL), SUCH AS A RELAY.

**Figure 2-40: Digital Outputs Connected in Current Sinking Mode**



 DIODE REQUIRED ON EACH OUTPUT THAT DRIVES AN INDUCTIVE DEVICE (COIL), SUCH AS A RELAY.

### 2.5.4. Digital Inputs

You can connect the digital inputs to current sourcing or current sinking devices but you must connect all four inputs in the same configuration. Refer to [Figure 2-42](#) and [Figure 2-43](#). The digital inputs are not designed for high-voltage isolation applications. They should only be used with ground-referenced circuits.

**Table 2-41: Digital Input Specifications**


Input Voltage	Approximate Input Current	Turn On Time	Turn Off Time
+5 V to +24 V	6 mA	10 $\mu$ s	43 $\mu$ s

**Table 2-42: Digital Input Pins on the Auxiliary I/O Connector**


Pin#	Description	In/Out/Bi
17	Digital Input 0 / CCW EOT Input <sup>(1)</sup>	Input
18	Digital Input 1 / CW EOT Input <sup>(1)</sup>	Input
24	Digital Input Common	Output
25	Digital Input 2 / Home Input <sup>(1)</sup>	Input
26	Digital Input 3	Input

(1) Software configured option


**Figure 2-41: Digital Inputs Schematic (Aux I/O Connector)**



**Figure 2-42: Digital Inputs Connected to Current Sourcing Devices**



**Figure 2-43: Digital Inputs Connected to Current Sinking Devices**



### 2.5.5. High-Speed Inputs

High-speed inputs 20 and 21 can be used as general purpose inputs or as the trigger signal for high speed data collection. Refer to the [DriveDataCaptureConfigureTrigger\(\) function \[A3200: DATAACQ TRIGGER command\]](#) topic in the Help file for more information.

You can use the external [PSO synchronization functions \[A3200: PSOOUTPUT PULSE EXTSYNC command\]](#) to synchronize waveform generation with an external synchronization signal. When you activate this feature, the PSO Waveform module will not generate the configured waveform when an output event is received until the rising edge of the synchronization signal occurs.


**Table 2-43: High-Speed Input Specifications**

Specification	Value
Input Voltage	5V - 24 V input voltages
Input Current	10 mA
Input Device	HCPL-0630
Delay	50 nsec

**Table 2-44: High-Speed Input Pins on the Auxiliary I/O Connector**

Pin#	Description	In/Out/Bi
3	High-Speed Input 20 + / PSO External Sync. +	Input
4	High-Speed Input 20 - / PSO External Sync. -	Input
5	High-Speed Input 21 +	Input
6	High-Speed Input 21 -	Input

**Figure 2-44: High-Speed Inputs**



### 2.5.6. Analog Output 0

The analog output can be set from within a program or it can be configured to echo the state of select servo loop nodes.

The analog output is set to zero when you power on the system or reset the drive.


**Table 2-45: Analog Output Specifications**

Specification	Value
Output Voltage	-10 V to +10 V
Output Current	5 mA
Resolution (bits)	16 bits

**Table 2-46: Analog Output Pins on the Auxiliary I/O Connector**

Pin#	Description	In/Out/Bi
22	Analog Output 0	Output
23	Analog Common	Output

**Figure 2-45: Analog Output 0 Schematic**



### 2.5.7. Analog Input 0 (Differential)

To interface to a single-ended, non-differential voltage source, connect the signal common of the source to the negative input and connect the analog source signal to the positive input. A floating signal source must be referenced to the analog common. Refer to [Figure 2-46](#).


**Table 2-47: Analog Input Specifications**

Specification	Value
(AI+) - (AI-)	+10 V to -10 V <sup>(1)</sup>
Resolution (bits)	16 bits
Input Impedance	1 M $\Omega$
1. Signals outside of this range may damage the input	

**Table 2-48: Analog Input Pins on the Auxiliary I/O Connector**

Pin#	Description	In/Out/Bi
13	Analog Input 0+ (Differential)	Input
14	Analog Input 0- (Differential)	Input
23	Analog Common	Output

**Figure 2-46: Analog Input 0 Schematic**



## 2.6. Brake Power Supply Connector

This port is the power supply connection to the on-board brake control circuit. Refer to [Section 2.3.6](#) for more information about the brake output interface.

**Table 2-49: Brake Power Supply Connector Pinout**

Pin#	Description	In/Out/BI	Connector
1	Brake Power Supply (+)	Input	
2	Brake Power Supply (-)	Input	

**Table 2-50: Mating Connector Part Numbers for the Brake Power Supply Connector**

Description	Aerotech P/N	Phoenix P/N	Tightening Torque (Nm)	Wire Size: AWG [mm <sup>2</sup> ]
2-Pin Terminal Block	ECK02390	1827616	0.22 - 0.25	0.14 - 1.5 [26-16]

## 2.7. HyperWire Interface

The HyperWire bus is the high-speed communications connection from the controller. It operates at 2 gigabits per second. The controller sends all command and configuration information through the HyperWire bus.

HyperWire cables can be safely connected to or disconnected from a HyperWire port while the PC and/or drive is powered on. However, any changes to the HyperWire network topology will disrupt communication and you must reset the controller to re-establish communication.



**WARNING:** Do not connect or disconnect HyperWire cables while you are loading firmware or damage to the drives may occur.

**Table 2-51: HyperWire Card Part Number**

Part Number	Description
HYPERWIRE-PCIE	HyperWire adapter, PCIe x4 interface

**Table 2-52: HyperWire Cable Part Numbers**

Part Number	Description
HYPERWIRE-AO10-5	HyperWire cable, active optical, 0.5 m
HYPERWIRE-AO10-10	HyperWire cable, active optical, 1.0 m
HYPERWIRE-AO10-30	HyperWire cable, active optical, 3.0 m
HYPERWIRE-AO10-50	HyperWire cable, active optical, 5.0 m
HYPERWIRE-AO10-200	HyperWire cable, active optical, 20.0 m

## 2.8. External Shunt Option [-SX1]



**DANGER:** The shunt resistor dissipates a high quantity of power. To prevent the danger of electric shock or fire, you must obey the precautions that follow:

- Correctly size, mount, and protect the external shunt resistor.
- Do not touch the shunt resistor terminals. There are lethal voltages on the terminals.
- Do not touch the surface of the drive or the external shunt resistor. The temperature can exceed 70°C.
- Restrict access to the shunt resistor while it is connected to a power source.

The -SX1 option provides a connection for a user-provided shunt resistor to dissipate excess energy and keep the internal drive voltage within safe levels. The drive switches this resistor "ON" when the internal bus voltage reaches approximately 380 VDC. This option is generally required for systems that have a large amount of stored mechanical energy that must be dissipated during deceleration.

**Table 2-53: -SX1 Component Information**

Component	Description	Aerotech P/N
Recommended Shunt Resistor	50 Ω (min), 300 W Vishay/Dale: RBEF030050R00KFBVT	ECR01039
1-Pin Mating Connector [QTY. 2]	<b>Screw Torque Value:</b> 0.6 - 0.8 N·m <b>Wire Size:</b> 0.2 - 6 mm <sup>2</sup> [24-10 AWG] Phoenix: 0708250	ECK02452
F101 Fuse on the Control Board	8 A S.B.	EIF01022
Recommended Wire Size	16 AWG (1.3 mm <sup>2</sup> ) High Temperature	--

### Equation 1:

Calculate the kinetic energy of the system. Any energy that is not lost to the system could be regenerated to the DC bus.

$$E_M = \left[ \frac{1}{2} \right] [J_M + J_L] \omega_M^2 \quad \text{or} \quad E_M = \left[ \frac{1}{2} \right] [M_M + M_L] v_M^2$$

(for rotary motors) (for linear motors)

$J_M$	rotor inertia (kg·m <sup>2</sup> )
$J_L$	load inertia (kg·m <sup>2</sup> )
$\omega_m$	motor speed before deceleration (rad/s)
$M_M$	forcer mass (kg)
$M_L$	load mass (kg)
$v_m$	velocity (m/s)

### Equation 2:

You will need a shunt resistor if the regenerated energy is greater than the Maximum Additional Storage Energy that the internal bus capacitor can store (Table 2-54).

$$E_{Ca} = \frac{1}{2} C (V_M^2 - V_{NOM}^2)$$

$C$	bus capacitor (F) [1,200 μF]
$V_M$	turn on voltage for shunt circuit (V) [380 V]
$V_{NOM}$	nominal bus voltage (V) [160 V or 320 V, Typical] [160 V or 320 V, Typical]

**Table 2-54: Maximum Additional Storage Energy for a Standard iXC4/XC4**

Bus Voltage	Maximum Additional Energy
160 V	71.3 J
320 V	25.2 J

If a shunt resistor is required, calculate the value of resistance necessary to dissipate the energy.

**Equations 3, 4, and 5:**

Calculate the parameters of the shunt resistor.

**Equation 3:**

$$P_{PEAK} = \frac{E_M - E_{Ca}}{t_D}$$

$P_{PEAK}$  peak power that the regeneration circuit must accommodate (W)  
 $t_D$  deceleration time (s)

**Equation 4:**

$$P_{AV} = \frac{E_M - E_{Ca}}{t_{CYCLE}}$$

$P_{AV}$  average power dissipated on shunt resistor (W)  
 $t_{CYCLE}$  time between deceleration events (s)

**Equation 5:**

$$R = \frac{(2V_M - V_{HYS})^2}{4P_{PEAK}}$$

$V_{HYS}$  hysteresis voltage of regeneration circuit (V) [10 V, Typical]

**Additional useful equations:**

1 lb·ft = 1.356 N·m

1 rad/s = 9.55 rpm

## 2.9. Sync Port

The Sync port is a bi-directional high speed proprietary interface that lets you transmit encoder signals between drives. This is typically used for multi-axis PSO applications where one or two drives send their encoder signals to a main drive that has the PSO logic and PSO output signal. The drive contains two Sync ports, labeled A and B.

To avoid signal contention, all Sync ports default to the input state during reset and immediately after power is applied to the drive.

**Table 2-55: Sync-Related Functions**

Function	Description
DriveEncoderOutputConfigureDivider(), DriveEncoderOutputConfigureInput(), DriveEncoderOutputOn(), DriveEncoderOutputOff() [A3200: ENCODER OUT command]	Configure each Sync port as an input or an output
PsoDistanceConfigureInputs() [A3200: PSOTRACK INPUT command]	Let the PSO to track the SYNC A or SYNC B port.
PsoWindowConfigureInput() [A3200: PSOWINDOW INPUT command]	

The Sync port uses low-voltage differential signaling (LVDS) and standard USB 3.0 type A (cross over) cables.

**Table 2-56: Sync Port Cables**

Part Number	Description
CBL-SYNC-3	Length 3 dm; Connectors: USB Type A to USB Type A
CBL-SYNC-5	Length 5 dm; Connectors: USB Type A to USB Type A
CBL-SYNC-7	Length 7 dm; Connectors: USB Type A to USB Type A
CBL-SYNC-10	Length 10 dm; Connectors: USB Type A to USB Type A

## 2.10. Industrial Ethernet (iXC4 Only)

The controller is equipped with 100BASE-TX Industrial Ethernet ports.



**IMPORTANT:** Industrial Ethernet is only available on the iXC4.

- For the location of the ports, refer to [Figure 1-1](#).
- For cable part numbers, refer to [Table 4-1](#).
- For more information, refer to the Help system.

## 2.11. System Interconnection

Figure 2-47: Drive-Based System Wiring Drawing (Best Practice)




Figure 2-48: PC-Based System Wiring Drawing (Best Practice)






Figure 2-49: Drive-Based Controller System Interconnection (Best Practice)



<p><b>! ATTENTION !</b></p> <p>The system integrator or end user is responsible for all safety compliance and technical requirements for the system wiring.</p> <p><b>IMPORTANT:</b> Read all parts of this manual before you install or operate the XLS or before you do maintenance to your system.</p> <ul style="list-style-type: none"> <li>To prevent injury to you and damage to the equipment, obey the precautions in this manual.</li> <li>If you do not understand the information in this manual, contact Aerotech Global Technical Support.</li> </ul> <p>For EMC performance, mount all system components on to a common <b>conductive</b> metal panel.</p> <ul style="list-style-type: none"> <li>Do not use a panel that has a <b>painted</b> or <b>nonconductive</b> coat applied.</li> <li>You can use a panel with a <b>conductive</b> surface coat.</li> </ul> <p><b>Customer-supplied wiring</b></p> <ul style="list-style-type: none"> <li>The system integrator is responsible for all safety compliance and technical requirements.</li> <li>Aerotech recommends that you use AC1 &amp; AC2 twisted pair conductors with critical runs as short as possible.</li> <li>When routing conductors, keep high-voltage supply wiring separated from low-voltage I/O or control/feedback signal wiring.</li> </ul>	<p>Alternate Motor Supply transformer (for reference only)</p> <p><b>System Protective Earth (PE) grounds</b></p> <ul style="list-style-type: none"> <li>Keep PE wires as short as possible</li> <li>Each PE wire should have a dedicated attachment/termination point</li> <li>Aerotech recommends that you should terminate each PE directly to the grounded component panel. Refer to Note 1 above.</li> </ul> <p><b>XC4, iXC4, XC4e, and iXC4e Controllers</b></p> <ul style="list-style-type: none"> <li>Refer to assemblies (A1), (A2), and (A3)</li> <li>If the controllers were purchased as an integrated system, refer to the System Interconnections Drawing included with the system documentation. Note that a controller's serial number is specific to an assigned axis.</li> </ul> <p><b>OPTIONAL EQUIPMENT: MFM10-1 (Motor Filter Module with 10ARMS Cable)</b></p> <ul style="list-style-type: none"> <li>Refer to assemblies (A6), (A7), and (A8)</li> <li>For mechanical and electrical descriptions of the MFM10-1, refer to the Motor Filter Module Hardware Manual (MFM.pdf) at <a href="http://www.aerotechmotioncontrol.com/manuals/index.aspx">http://www.aerotechmotioncontrol.com/manuals/index.aspx</a>. Find the manual under the Controller Accessories dropdown.</li> </ul> <p>If the MFM10-1 is not used, connect the system motor cable directly to the controller M3/CRK OUTPUT terminals</p>	<p><b>UFM-ST (Filter: AC Line Enclosure)</b></p> <ul style="list-style-type: none"> <li>Refer to assemblies (A4) and (A5)</li> <li>For mechanical and electrical descriptions of the UFM-ST, refer to the UFM-ST Hardware Manual (UFMST.pdf) at <a href="http://www.aerotechmotioncontrol.com/manuals/index.aspx">http://www.aerotechmotioncontrol.com/manuals/index.aspx</a>. Find the manual under the Controller Accessories dropdown.</li> </ul> <p><b>Axis FEEDBACK cable Ferrite EMC Filters</b></p> <ul style="list-style-type: none"> <li>P/N: Ferr-Filter #0446167281 (Aerotech # EC202348)</li> <li>Clamp-On Construction</li> <li>Apply as close as possible to the FEEDBACK connector as illustrated</li> </ul> <p><b>XC4/XC4e Controller Control Power and Motor Power - and- UFM-ST Ferrite EMC Filters</b></p> <ul style="list-style-type: none"> <li>P/N: Ferr-Filter #0446164281 (Aerotech # EC202347)</li> <li>Clamp-On Construction</li> <li>Apply as close as possible to the power connector as illustrated</li> </ul> <p><b>System AC Supply Ferrite EMC Filter</b></p> <ul style="list-style-type: none"> <li>P/N: Ferr-Filter #2002020-300 (Aerotech # EC202398)</li> <li>Torsion Ring Construction</li> <li>Loop System AC1 and AC2 conductor pair two times through the toroid</li> </ul> <p><b>System AC Power</b></p> <ul style="list-style-type: none"> <li>If AC2 is not referenced to NEUTRAL, the AC2 line must have a fuse or circuit breaker protection</li> </ul> <p>The information on this page is for reference only and represents best practice applications.</p>
---	--	---

Figure 2-50: PC-Based Controller System Interconnection (Best Practice)



<p><b>! ATTENTION !</b></p> <p>The system integrator or end user is responsible for all safety compliance and technical requirements for the system wiring.</p> <p><b>IMPORTANT:</b> Read all parts of this manual before you install or operate the XLS or before you do maintenance to your system.</p> <ul style="list-style-type: none"> <li>To prevent injury to you and damage to the equipment, obey the precautions in this manual.</li> <li>If you do not understand the information in this manual, contact Aerotech Global Technical Support.</li> </ul> <p>For EMC performance, mount all system components on to a common conductive metal panel.</p> <ul style="list-style-type: none"> <li>Do not use a panel that has a painted or non-conductive coat applied.</li> <li>You can use a panel with a conductive surface coat.</li> </ul> <p><b>Customer-supplied wiring</b></p> <ul style="list-style-type: none"> <li>The system integrator is responsible for all safety compliance and technical requirements.</li> <li>Aerotech recommends that you use AC1 &amp; AC2 twisted pair conductors with critical runs as short as possible.</li> <li>When routing conductors, keep high-voltage supply wiring separated from low-voltage I/O or control/feedback signal wiring.</li> </ul>	<p>Alternate Motor Supply transformer (for reference only)</p> <p><b>System Protective Earth (PE) grounds</b></p> <ul style="list-style-type: none"> <li>Keep PE wires as short as possible</li> <li>Each PE wire should have a dedicated attachment/termination point</li> <li>Aerotech recommends that you should terminate each PE directly to the grounded component panel. Refer to Note 1 above.</li> </ul> <p><b>XC4 and XC4e Controllers</b></p> <ul style="list-style-type: none"> <li>Refer to assemblies (A1), (A2), and (A3)</li> <li>If the controllers were purchased as an integrated system, refer to the System Interconnections Drawing included with the system documentation. Note that a controller's serial number is specific to an assigned axis.</li> </ul> <p><b>OPTIONAL EQUIPMENT: MFM10-1 (Motor Filter Module with 10ARMS Cable)</b></p> <ul style="list-style-type: none"> <li>Refer to assemblies (A6), (A7), and (A8)</li> <li>For mechanical and electrical descriptions of the MFM10-1, refer to the Motor Filter Module Hardware Manual (MFM) pdf at <a href="http://www.aerotechmotioncontrol.com/manuals/index.aspx">http://www.aerotechmotioncontrol.com/manuals/index.aspx</a></li> <li>Find the manual under the Controller Accessories dropdown.</li> </ul> <p>If the MFM10-1 is not used, connect the system motor cable directly to the controller M3/MCR OUTPUT terminals</p>	<p><b>UFM-ST Filter: AC Line Enclosure</b></p> <ul style="list-style-type: none"> <li>Refer to assemblies (A4) and (A5)</li> <li>For mechanical and electrical descriptions of the UFM-ST, refer to the UFM-ST Hardware Manual (UFMS) pdf at <a href="http://www.aerotechmotioncontrol.com/manuals/index.aspx">http://www.aerotechmotioncontrol.com/manuals/index.aspx</a></li> <li>Find the manual under the Controller Accessories dropdown.</li> </ul> <p><b>Axis FEEDBACK cables Ferrite EMI Filters</b></p> <ul style="list-style-type: none"> <li>P/N: Ferr-Rely #0446167281 (Aerotech # EC202348)</li> <li>Cramp-On Construction</li> <li>Apply as close as possible to the FEEDBACK connector as illustrated</li> </ul> <p><b>XC4/XC4e Controller Control Power and Motor Power - and UFM-ST Ferrite EMI Filters</b></p> <ul style="list-style-type: none"> <li>P/N: Ferr-Rely #0446164281 (Aerotech # EC202347)</li> <li>Cramp-On Construction</li> <li>Apply as close as possible to the power connector as illustrated</li> </ul> <p><b>System AC Supply Ferrite EMI Filter</b></p> <ul style="list-style-type: none"> <li>P/N: Ferr-Rely #020020-300 (Aerotech # EC202398)</li> <li>Cramp-On Construction</li> <li>Loop System AC1 and AC2 conductor pair two times through the toroid</li> </ul> <p><b>System AC Power</b></p> <ul style="list-style-type: none"> <li>If AC2 is not referenced to NEUTRAL, the AC2 line must have a fuse or circuit breaker protection</li> </ul> <p>The information on this page is for reference only and represents best practice applications.</p>
--	--	---


## 2.12. PC Configuration and Operation Information

For more information about hardware requirements, PC configuration, programming, system operation, and utilities, refer to the [Help file](#).

# Chapter 3: -EB1 Option Expansion Board

The -EB1 I/O option board has 16 digital inputs, 16 digital outputs, 3 analog inputs, 3 analog outputs, and PSO outputs.

**Figure 3-1: -EB1 I/O Option Board Connectors (iXC4 shown)**



### 3.1. Digital Outputs [-EB1]

Optically-isolated solid-state relays drive the digital outputs. You can connect the digital outputs in current sourcing or current sinking mode but you must connect all four outputs in a port in the same configuration. Refer to [Figure 3-3](#) and [Figure 3-4](#).

The digital outputs are not designed for high-voltage isolation applications and they should only be used with ground-referenced circuits.


You must install suppression diodes on digital outputs that drive relays or other inductive devices. To see an example of a current sourcing output that has diode suppression, refer to [Figure 3-3](#). To see an example of a current sinking output that has diode suppression, refer to [Figure 3-4](#).

The digital outputs have overload protection. They will resume normal operation when the overload is removed.

**Table 3-1: Digital Output Specifications [-EB1]**

Digital Output Specifications	Value
Maximum Voltage	24 V (26 V Maximum)
Maximum Sink/Source Current	250 mA/output
Output Saturation Voltage	0.9 V at maximum current
Output Resistance	3.7 $\Omega$
Rise / Fall Time	250 $\mu$ s (2K pull up to 24V)
Reset State	Output Off (High Impedance State)


**Table 3-2: Digital Output 1 Connector Pinout [-EB1]**

Pin#	Description	In/Out/Bi	Connector
1	Output Common for Outputs 4-7	Output	
2	Output 4 (Optically-Isolated)	Output	
3	Output 5 (Optically-Isolated)	Output	
4	Output 6 (Optically-Isolated)	Output	
5	Output 7 (Optically-Isolated)	Output	
6	Output Common for Outputs 8-11	Output	
7	Output 8 (Optically-Isolated)	Output	
8	Output 9 (Optically-Isolated)	Output	
9	Output 10 (Optically-Isolated)	Output	
10	Output 11 (Optically-Isolated)	Output	

**Table 3-3: Mating Connector Part Numbers for the Digital Output 1 Connector [-EB1]**

Mating Connector	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
10-Pin Terminal Block	ECK02395	Phoenix 1700841	0.5 - 0.14 [20-26]


**Table 3-4: Digital Output 2 Connector Pinout [-EB1]**

Pin#	Description	In/Out/Bi	Connector
1	Output Common for Outputs 12-15	Output	
2	Output 12 (Optically-Isolated)	Output	
3	Output 13 (Optically-Isolated)	Output	
4	Output 14 (Optically-Isolated)	Output	
5	Output 15 (Optically-Isolated)	Output	
6	Output Common for Outputs 16-19	Output	
7	Output 16 (Optically-Isolated)	Output	
8	Output 17 (Optically-Isolated)	Output	
9	Output 18 (Optically-Isolated)	Output	
10	Output 19 (Optically-Isolated)	Output	

**Table 3-5: Mating Connector Part Numbers for the Digital Output 2 Connector [-EB1]**


Mating Connector	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
10-Pin Terminal Block	ECK02395	Phoenix 1700841	0.5 - 0.14 [20-26]

**Figure 3-2: Digital Outputs Schematic [-EB1]**



**Figure 3-3: Digital Outputs Connected in Current Sourcing Mode [-EB1]**


Digital Output Connector [-EB1]



DIODE REQUIRED ON EACH OUTPUT THAT DRIVES AN INDUCTIVE DEVICE (COIL), SUCH AS A RELAY.

**Figure 3-4: Digital Outputs Connected in Current Sinking Mode [-EB1]**

Digital Output Connector [-EB1]



DIODE REQUIRED ON EACH OUTPUT THAT DRIVES AN INDUCTIVE DEVICE (COIL), SUCH AS A RELAY.

### 3.2. Digital Inputs [-EB1]

Input bits are arranged in groups of 4 and each group shares a common pin. This lets a group be connected to current sourcing or current sinking devices, based on the connection of the common pin in that group.

To be able to connect an input group to current sourcing devices, connect the input group's common pin to the power supply return (-). Refer to [Figure 3-6](#).


To be able to connect an input group to current sinking devices, connect the input group's common pin to the power supply source (+). Refer to [Figure 3-7](#).

The digital inputs are not designed for high-voltage isolation applications. They should only be used with ground-referenced circuits.

**Table 3-6: Digital Input Specifications [-EB1]**

Input Voltage	Approximate Input Current	Turn On Time	Turn Off Time
+5 V to +24 V	6 mA	10 $\mu$ s	43 $\mu$ s


**Table 3-7: Digital Input 1 Connector Pinout [-EB1]**

Pin#	Description	In/Out/Bi	Connector
1	Input Common for Inputs 4-7	Output	
2	Input 4 (Optically-Isolated)	Input	
3	Input 5 (Optically-Isolated)	Input	
4	Input 6 (Optically-Isolated)	Input	
5	Input 7 (Optically-Isolated)	Input	
6	Input Common for Inputs 8-11	Output	
7	Input 8 (Optically-Isolated)	Input	
8	Input 9 (Optically-Isolated)	Input	
9	Input 10 (Optically-Isolated)	Input	
10	Input 11 (Optically-Isolated)	Input	

**Table 3-8: Mating Connector Part Numbers for the Digital Input 1 Connector [-EB1]**

Mating Connector	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
10-Pin Terminal Block	ECK02395	Phoenix 1700841	0.5 - 0.14 [20-26]


**Table 3-9: Digital Input 2 Connector Pinout [-EB1]**

Pin#	Description	In/Out/Bi	Connector
1	Input Common for Inputs 12-15	Output	
2	Input 12 (Optically-Isolated)	Input	
3	Input 13 (Optically-Isolated)	Input	
4	Input 14 (Optically-Isolated)	Input	
5	Input 15 (Optically-Isolated)	Input	
6	Input Common for Inputs 16-19	Output	
7	Input 16 (Optically-Isolated)	Input	
8	Input 17 (Optically-Isolated)	Input	
9	Input 18 (Optically-Isolated)	Input	
10	Input 19 (Optically-Isolated)	Input	

**Table 3-10: Mating Connector Part Numbers for the Digital Input 2 Connector [-EB1]**

Mating Connector	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
10-Pin Terminal Block	ECK02395	Phoenix 1700841	0.5 - 0.14 [20-26]


**Figure 3-5: Digital Inputs Schematic [-EB1]**






**IMPORTANT:** Each bank of four inputs must be connected in an all sourcing or all sinking configuration.

**Figure 3-6: Digital Inputs Connected to Current Sourcing (PNP) Devices [-EB1]**



**Figure 3-7: Digital Inputs Connected to Current Sinking (NPN) Devices [-EB1]**



### 3.3. Analog Outputs [-EB1]


The analog outputs can be set from within a program or they can be configured to echo the state of select servo loop nodes.

The analog outputs are set to zero when you power on the system or reset the drive.

**Table 3-11: Analog Output Specifications [-EB1]**

Specification	Value
Output Voltage	-10 V to +10 V
Output Current	5 mA
Resolution (bits)	16 bits


**Table 3-12: Analog Output Connector Pinout [-EB1]**

Pin #	Description	In/Out/Bi	Connector
1	Analog Output 1	Output	
2	Analog Output 2	Output	
3	Analog Output 3	Output	
4	Ground	N/A	

**Table 3-13: Mating Connector Part Numbers for the Analog Output Connector [-EB1]**

Type	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
4-Pin Terminal Block	ECK02399	Phoenix 1768004	0.5- 0.14 [20-26]

**Figure 3-8: Analog Output Typical Connection [-EB1]**



### 3.4. Analog Inputs [-EB1]

To interface to a single-ended, non-differential voltage source, connect the signal common of the source to the negative input and connect the analog source signal to the positive input. A floating signal source must be referenced to the analog common. Refer to [Figure 3-9](#).

**Table 3-14: Differential Analog Input Specifications [-EB1]**

Specification	Value
(AI+) - (AI-)	+10 V to -10 V <sup>(1)</sup>
Resolution (bits)	16 bits
Input Impedance	1 MΩ
1. Signals outside of this range may damage the input	


**Table 3-15: Analog Input Connector Pinout [-EB1]**

Pin#	Description	In/Out/Bi	Connector
1	+5V (250 mA max)	Output	
2	Analog Input 1+	Input	
3	Analog Input 1-	Input	
4	Analog Input 2+	Input	
5	Analog Input 2-	Input	
6	Analog Input 3+	Input	
7	Analog Input 3-	Input	
8	Ground	N/A	

**Table 3-16: Mating Connector Part Numbers for the Analog Input Connector [-EB1]**

Mating Connector	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
8-Pin Terminal Block	ECK02397	Phoenix 1908101	0.5 - 0.14 [20-26]

**Figure 3-9: Analog Input Typical Connection [-EB1]**



### 3.5. PSO Interface [-EB1]

The Position Synchronized Output (PSO) signal is available on the -EB1 option board in two signal formats: TTL and Isolated.

The PSO signal is also available on the AUX I/O connector. Refer to [Section 2.5.2](#).

You cannot use a sine wave encoder with the -MX1 multiplier option as an input to the PSO. The -MX1 option does not generate emulated quadrature signals.

**Table 3-17: PSO Specifications [-EB1]**

Specification		Value
Output	TTL	5 V, 50 mA (max)
	Isolated	5-24 V, 250 mA
Maximum PSO Output (Fire) Frequency	TTL	12.5 MHz
	Isolated	5 MHz
Output Latency [Fire event to output change]	TTL	5 ns
	Isolated	150 ns

**Table 3-18: PSO Interface Connector Pinout [-EB1]**

Pin #	Description	In/Out/Bi	Connector
1	PSO Output+	Output	
2	PSO Output-	Output	
3	PSO Output (TTL)	Output	
4	Ground	N/A	


**Table 3-19: Mating Connector Part Numbers for the PSO Interface Connector [-EB1]**

Type	Aerotech P/N	Third Party P/N	Wire Size: mm <sup>2</sup> [AWG]
4-Pin Terminal Block	ECK02399	Phoenix 1768004	0.5- 0.14 [20-26]


**Isolated Signals**

This output signal is a fully-isolated 5-24V compatible output capable of sourcing or sinking current. This output is normally open and only conducts current when a PSO fire event occurs. The PSO Isolated Outputs are overload protected and will turn off if the maximum output current is exceeded.

**Figure 3-10: PSO Output Sources Current**




**Figure 3-11: PSO Output Sinks Current**



**TTL Signals**

This output signal is a 5V TTL signal which is used to drive an opto coupler or general purpose TTL input. This signal is active high and is driven to 5V when a PSO fire event occurs.

**Figure 3-12: PSO TTL Outputs Schematic**



## Chapter 4: Cables and Accessories



**IMPORTANT:** Find Aerotech cable drawings on the website at <http://www.aerotechmotioncontrol.com/manuals/index.aspx>.

**Table 4-1: Standard Interconnection Cables**

Cable Part #	Description
Joystick	Refer to <a href="#">Section 4.1</a> .
ECZ01231	BBA32 Interconnect Cable
ENET-CAT5e-xx <sup>(1, 2)</sup>	Ethernet CAT5e Cable
USB-AMCM-xx <sup>(1, 2)</sup>	USB Cable A-Male to C-Male
(1) The "-xx" indicates length in decimeters.	
(2) iXC4 Only	

### 4.1. Joystick Interface

Aerotech Multi-Axis Joystick (NEMA12 (IP54) rated) is powered from 5 V and has a nominal 2.5 V output in the center detent position. Three buttons are used to select axis pairs and speed ranges. Joystick control will not activate unless the joystick is in the center location. Third party devices can be used provided they produce a symmetric output voltage within the range of -10 V to +10 V.

Connecting joystick with an Aerotech cable, all Aerotech cables are labeled to identify the connector and connections. The joystick parameters must be set to match the analog and digital I/O connections. Refer to the [Help file](#) for programming information about how to change joystick parameters.

**Figure 4-1: Two Axis Joystick Interface (to the Aux I/O of two drives)**





Figure 4-2: Two Axis Joystick Interface (to the I/O board)



### 4.2. Handwheel Interface


A handwheel can be used to manually control axis position. The handwheel must provide 5V differential quadrature signals to the drive.




**IMPORTANT:** You can find instructions on how to enable the handwheel in the online [Help file](#).

Connect a handwheel to the Aux I/O as shown in [Figure 4-3](#) or [Figure 4-4](#).

**Figure 4-3: Handwheel Interconnection to Aux I/O Connector**



**Figure 4-4: Handwheel Interconnection to the Aux I/O through a BBA32 Module**



## Chapter 5: Maintenance



**IMPORTANT:** For your own safety and for the safety of the equipment:

- Do not remove the cover of the iXC4/XC4.
- Do not attempt to access the internal components.

A fuse that needs to be replaced indicates that there is a more serious problem with the system or setup. Contact Global Technical Support for assistance.



**DANGER:** If you must remove the covers and access any internal components be aware of the risk of electric shock.

1. Disconnect the Mains power connection.
2. Wait at least ten (10) minutes after removing the power supply before doing maintenance or an inspection. Otherwise, there is the danger of electric shock.
3. All tests must be done by an approved service technician. Voltages inside the controller and at the input and output power connections can kill you.

**Table 5-1: LED Description**

LED	Color	Description
PWR	GREEN	The light will illuminate and remain illuminated while power is applied.
EN/FLT	GREEN	The axis is Enabled.
	RED	The axis is in a Fault Condition.
	GREEN/RED (alternates)	The axis is Enabled in a Fault Condition. or The light is configured to blink for setup.

**Table 5-2: Troubleshooting**

Symptom	Possible Cause and Solution
No Communication	Make sure the power LED is illuminated (this indicates that power is present).
	Make sure that all communication cables (HyperWire, for example) are fully inserted in their ports.

## 5.1. Preventative Maintenance

Do an inspection of the iXC4/XC4 and the external wiring one time each month. It might be necessary to do more frequent inspections based on:

- The operating conditions of the system.
- How you use the system.

**Table 5-3: Preventative Maintenance**

Check	Action to be Taken
Examine the chassis for hardware and parts that are damaged or loose. It is not necessary to do an internal inspection unless you think internal damage occurred.	Repair all damaged parts.
Do an inspection of the cooling vents.	Remove all material that collected in the vents.
Examine the work area to make sure there are no fluids and no electrically conductive materials.	Do not let fluids and electrically conductive material go into the chassis.
Examine all cables and connections to make sure they are correct.	Make sure that all connections are correctly attached and not loose. Replace cables that are worn. Replace all broken connectors.

### Cleaning



**DANGER:** Before you clean the iXC4/XC4, disconnect the electrical power from the drive.

Use a clean, dry, soft cloth to clean the iXC4/XC4. If necessary, use a cloth that is moist with water or isopropyl alcohol. If you use a moist cloth, make sure that moisture does not go into the drive. Also make sure that it does not go onto the outer connectors and components. Internal contamination from the cleaning solution can cause corrosion and electrical short circuits.

Do not clean the labels with a cleaning solution because it might remove the label information.

## 5.2. Fuse Specifications



**WARNING:** Replace fuses only with the same type and value.

**Table 5-4: Control Board Fuse Specifications**

Fuse	Description	Size	SCCR (1)	Aerotech P/N	Third Party P/N
F100	Control Power at Line Input (L)	2 A S.B.	35 A	EIF01044	Littelfuse 0877002.MXEP
F101	-SX1 (External Shunt) Option	8 A S.B.	1500 A	EIF01022	Littelfuse 0215008.HXP
F102	Motor Bus Supply at AC1 (-10 Peak Current Option)	5 A S.B.	1500 A	EIF01023	Littelfuse 215005.HXP
	Motor Bus Supply at AC1 (-20/-30 Peak Current Option)	10 A S.B.		EIF01020	Littelfuse 0215010.HXP

(1) Short circuit current rating.

*This page intentionally left blank.*

## Appendix A: Warranty and Field Service

Aerotech, Inc. warrants its products to be free from harmful defects caused by faulty materials or poor workmanship for a minimum period of one year from date of shipment from Aerotech. Aerotech's liability is limited to replacing, repairing or issuing credit, at its option, for any products that are returned by the original purchaser during the warranty period. Aerotech makes no warranty that its products are fit for the use or purpose to which they may be put by the buyer, whether or not such use or purpose has been disclosed to Aerotech in specifications or drawings previously or subsequently provided, or whether or not Aerotech's products are specifically designed and/or manufactured for buyer's use or purpose. Aerotech's liability on any claim for loss or damage arising out of the sale, resale, or use of any of its products shall in no event exceed the selling price of the unit.

THE EXPRESS WARRANTY SET FORTH HEREIN IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE. IN NO EVENT SHALL AEROTECH BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES.

### Return Products Procedure

Claims for shipment damage (evident or concealed) must be filed with the carrier by the buyer. Aerotech must be notified within thirty (30) days of shipment of incorrect material. No product may be returned, whether in warranty or out of warranty, without first obtaining approval from Aerotech. No credit will be given nor repairs made for products returned without such approval. A "Return Materials Authorization (RMA)" number must accompany any returned product(s). The RMA number may be obtained by calling an Aerotech service center or by submitting the appropriate request available on our website ([www.aerotech.com](http://www.aerotech.com)). Products must be returned, prepaid, to an Aerotech service center (no C.O.D. or Collect Freight accepted). The status of any product returned later than thirty (30) days after the issuance of a return authorization number will be subject to review.

Visit [Global Technical Support Portal](#) for the location of your nearest Aerotech Service center.

### Returned Product Warranty Determination

After Aerotech's examination, warranty or out-of-warranty status will be determined. If upon Aerotech's examination a warranted defect exists, then the product(s) will be repaired at no charge and shipped, prepaid, back to the buyer. If the buyer desires an expedited method of return, the product(s) will be shipped collect. Warranty repairs do not extend the original warranty period.

**Fixed Fee Repairs** - Products having fixed-fee pricing will require a valid purchase order or credit card particulars before any service work can begin.

**All Other Repairs** - After Aerotech's evaluation, the buyer shall be notified of the repair cost. At such time the buyer must issue a valid purchase order to cover the cost of the repair and freight, or authorize the product(s) to be shipped back as is, at the buyer's expense. Failure to obtain a purchase order number or approval within thirty (30) days of notification will result in the product(s) being returned as is, at the buyer's expense.

Repair work is warranted for ninety (90) days from date of shipment. Replacement components are warranted for one year from date of shipment.

### Rush Service

At times, the buyer may desire to expedite a repair. Regardless of warranty or out-of-warranty status, the buyer must issue a valid purchase order to cover the added rush service cost. Rush service is subject to Aerotech's approval.

### On-site Warranty Repair

If an Aerotech product cannot be made functional by telephone assistance or by sending and having the customer install replacement parts, and cannot be returned to the Aerotech service center for repair, and if Aerotech determines the problem could be warranty-related, then the following policy applies:

Aerotech will provide an on-site Field Service Representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs. For warranty field repairs, the customer will not be charged for the cost of labor and material. If service is rendered at times other than normal work periods, then special rates apply.

If during the on-site repair it is determined the problem is not warranty related, then the terms and conditions stated in the following "On-Site Non-Warranty Repair" section apply.

### On-site Non-Warranty Repair

If any Aerotech product cannot be made functional by telephone assistance or purchased replacement parts, and cannot be returned to the Aerotech service center for repair, then the following field service policy applies:

Aerotech will provide an on-site Field Service Representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs and the prevailing labor cost, including travel time, necessary to complete the repair.

### Service Locations

<http://www.aerotech.com/contact-sales.aspx?mapState=showMap>

#### **USA, CANADA, MEXICO**

Aerotech, Inc.  
Global Headquarters

#### **CHINA**

Aerotech China  
Full-Service Subsidiary

#### **GERMANY**

Aerotech Germany  
Full-Service Subsidiary

#### **TAIWAN**

Aerotech Taiwan  
Full-Service Subsidiary

#### **UNITED KINGDOM**

Aerotech United Kingdom  
Full-Service Subsidiary

## Appendix B: Revision History

Revision	Description
2.05	Added support for Industrial Ethernet
2.04	Added support for Three Phase Stepper Motors: <a href="#">Section 2.2.4</a> .
2.03	The following sections have been updated: <ul style="list-style-type: none"> <li>• <a href="#">Section 2.1.2</a>.</li> <li>• <a href="#">Section 5.2</a>.</li> </ul>
2.02	The following sections have been updated: <ul style="list-style-type: none"> <li>• <a href="#">EU Declaration of Conformity</a></li> <li>• <a href="#">Agency Approvals</a></li> <li>• Added iXC4</li> </ul>
2.01	<ul style="list-style-type: none"> <li>• Absolute Encoder support on the Auxiliary I/O connector has been added.</li> <li>• System Wiring (best practices) drawing has been added</li> </ul>
2.00	General Update
1.02	The following sections have been updated: <ul style="list-style-type: none"> <li>• <a href="#">Agency Approvals</a></li> <li>• <a href="#">Section 2.3.1. Primary Encoder Inputs</a></li> </ul>
1.01	The following sections have been updated: <ul style="list-style-type: none"> <li>• <a href="#">Section 2.1.2</a>.</li> <li>• <a href="#">Section 2.11</a>.</li> </ul>
1.00	New Manual

*This page intentionally left blank.*

# Index

## -EB1

Analog Inputs	98
Analog Outputs	97
Digital Inputs	94
Digital Outputs	90
I/O Option Board	89
Position Synchronized Output (PSO) Interface	99

## -MX1

50

## -SX1

External Shunt Option	82
-----------------------	----

## 2

2006/42/EC	9
2011/65/EU	9
2014/30/EU	9
2014/35/EU	9

## A

Absolute Encoder (Auxiliary I/O Connector)	69
Absolute Encoder (Feedback Connector)	49
Absolute Encoder Schematic (Auxiliary I/O Connector)	69
Absolute Encoder Schematic (Feedback Connector)	49
AC line filter	30
Agency Approvals	10
Altitude	26
Ambient Temperature	26
Analog Encoder (Auxiliary I/O Connector)	50
Analog Encoder Specifications (Feedback Connector)	50
Analog Input 0 on the Aux I/O Connector	79
Analog Input 0 Schematic (Aux I/O Connector)	79
Analog Input 0 Specifications (Aux I/O Connector)	79
Analog Input Connector [-EB1] Mating Connector Part Numbers	98
Analog Input Connector Pinout [-EB1]	98
Analog Input Pins (Aux I/O Connector)	79
Analog Input Typical Connection [-EB1]	98
Analog Inputs [-EB1]	98
Analog Output 0 on the Aux I/O Connector	78
Analog Output 0 Schematic (Aux I/O Connector)	78
Analog Output 0 Specifications (Aux I/O Connector)	78

Analog Output Connector [-EB1] Mating Connector Part Numbers	97
Analog Output Connector Pinout [-EB1]	97
Analog Output Pins (Aux I/O Connector)	78
Analog Output Specifications [-EB1]	97
Analog Output Typical Connection [-EB1]	97
Analog Outputs [-EB1]	97
Aux I/O Connector	
Analog Input 0	79
Analog Output 0	78
Auxiliary Encoder Inputs	67
Digital Inputs	75
Digital Outputs	72
High-Speed User Inputs	77
Position Synchronized Output	70
PSO	70
Aux I/O Connector Mating Connector Part Numbers	66
Auxiliary Encoder Inputs (Aux I/O Connector)	67
Auxiliary I/O Connector	66
Absolute Encoder	69
Analog Encoder	50
RS-422 Line Driver Encoder	68
Sine Wave Encoder	50
Square Wave Encoder	68
Auxiliary I/O Connector Pinout	66
Auxiliary I/O Pins (Aux I/O Connector)	67

## B

BiSS absolute encoder	49,69
Brake Connected to the Feedback Connector	59
Brake Control Relay Specifications	59
Brake Output Connector Pinout	80
Brake Output Pins on the Feedback Connector	59
Brake Outputs (Feedback Connector)	59
Brake Power Supply Connector	80
Brake Power Supply Connector Mating Connector Part Numbers	80
Brushless Motor Configuration (Motor Power Output Connector)	40
Brushless Motor Connections (Motor Power Output Connector)	40
Brushless Motor Phasing Goal	42
Brushless Motor Phasing Oscilloscope Example	42
Brushless Motor Powered Motor Phasing	41



Encoder Fault Input (Feedback Connector)	55	Analog Output Typical Connection [-EB1]	97
Encoder Fault Input Pin on the Feedback Connector	55	Brake Connected to the Feedback Connector	59
Encoder Input (Feedback Connector)	47	Brushless Motor Configuration (Motor Power Output Connector)	40
Encoder Input Pins on the Feedback Connector	47	Control Supply Connections	29
Encoder Phasing	52	DC Brush Motor Configuration (Motor Power Output Connector)	43
Encoder Phasing Reference Diagram	52	Digital Inputs Connected to a Current Sinking Device [-EB1]	96
End of Travel Limit Input (Feedback Connector)	56	Digital Inputs Connected to a Current Sourcing Device [-EB1]	96
End of Travel Limit Input Connections	57	Digital Inputs Connected to Current Sinking Devices (Aux I/O Connector)	76
End of Travel Limit Input Diagnostic Display	58	Digital Inputs Connected to Current Sourcing Devices (Aux I/O Connector)	76
End of Travel Limit Input Pins on the Feedback Connector	56	Digital Output Schematic (Aux I/O Connector)	73
End of Travel Limit Phasing	58	Digital Outputs Connected in Current Sinking Mode (Aux I/O Connector)	74
EnDat absolute encoder	49,69	Digital Outputs Connected in Current Sourcing Mode (Aux I/O Connector)	74
Environmental Specifications	26	Digital Outputs Schematic [-EB1]	92
EU 2015/863	9	End of Travel Limit Input Connections	57
examining parts		End of Travel Limit Input Diagnostic Display	58
cables	106	Hall-Effect Inputs Schematic	53
connections	106	High-Speed Inputs	77
examining, dangerous fluids	106	Home Limit Input Connections	57
examining, dangerous material	106	Home Limit Input Diagnostic Display	58
External Shunt Option [-SX1]	82	Isolated Output Current Sinks Schematic (PSO)	100
		Isolated Output Current Sources Schematic (PSO)	100
<b>F</b>		Motor Supply Connections	30
Feedback Connector	46	Outputs Connected in Current Sinking Mode [-IO]	93
Absolute Encoder	49	Outputs Connected in Current Sourcing Mode [-EB1]	93
Brake Outputs	59	Positive Motor Direction	41
Encoder Fault Input	55	PSO Isolated Output Sinks Current	100
Encoder Input	47	PSO Isolated Output Sources Current	100
End of Travel Limit Input	56	PSO TTL Outputs Schematic	100
Hall-Effect Inputs	53	Square Wave Encoder Inputs Schematic (Aux I/O Connector)	68
Home Limit Input	56	Square Wave Encoder Schematic (Feedback Connector)	48
Pinout	46	Stepper Motor Configuration	44
Primary Encoder Input	47	STO Timing	65
RS-422 Line Driver Encoder	48	Thermistor Input Schematic	54
Square Wave Encoder	48	Three Phase Stepper Motor Configuration	45
Thermistor Input	54	TTL Outputs Schematic (PSO)	100
Travel Limit Input	56	Typical STO Configuration	61
Feedback Monitoring	41	fluids, dangerous	106
Figure			
-EB1 I/O Option Board Connectors	89		
Absolute Encoder Schematic (Auxiliary I/O Connector)	69		
Absolute Encoder Schematic (Feedback Connector)	49		
Analog Input 0 Schematic (Aux I/O Connector)	79		
Analog Input Typical Connection [-EB1]	98		
Analog Output 0 Schematic (Aux I/O Connector)	78		

Functional Diagram	20		
Fuse Specifications	107		
Control Supply at L	107		
External Shunt (-SX1)	107		
Motor Supply at AC1	107		
		<b>H</b>	
Hall-Effect Feedback Pins on the Feedback Connector	53		
Hall-Effect Inputs (Feedback Connector)	53		
Hall-Effect Inputs Schematic	53		
Handling	13		
Handwheel Interconnection (to Aux I/O through a BBA32 Module)	104		
Handwheel Interconnection to the Aux I/O Connector	104		
Handwheel Interface	104		
High-Speed Input Pins on the Aux I/O Connector	77		
High-Speed Input Specifications	77		
High-Speed Inputs	77		
High-Speed User Inputs (Aux I/O Connector)	77		
Home Limit Input (Feedback Connector)	56		
Home Limit Input Connections	57		
Home Limit Input Diagnostic Display	58		
Home Limit Input Pins on the Feedback Connector	56		
Humidity	26		
HyperWire	81		
Cable Part Numbers	81		
Card Part Number	81		
		<b>I</b>	
I/O Option Board [-EB1]	89		
Input Power Connections	29		
inspecting cooling vents	106		
Inspection	106		
Installation and Configuration	29		
Installation Overview	14		
Introduction	17		
IP54 Compliant	23		
Isolated Output Current Sinks Schematic (PSO)	100		
Isolated Output Current Sources Schematic (PSO)	100		
Isolation	21		
		<b>J</b>	
Joystick Interface	102		
			<b>L</b>
			70
			<b>M</b>
		Maintenance	105
		material, electrically conductive	106
		Mating Connector	
		Analog Output Connector [-EB1]	97
		Mating Connector P/N	
		Analog Input Connector [-EB1]	98
		Aux I/O Connector	66
		Brake Power Supply Connector	80
		Control Supply Connector	29
		Digital Input 1 Connector [-EB1]	94
		Digital Input 2 Connector [-EB1]	95
		Digital Output 1 Connector [-EB1]	91
		Digital Output 2 Connector [-EB1]	91
		Feedback Connector	46
		Motor Power Output Connector	39
		Motor Supply Connector	30
		PSO Connector [-EB1]	99
		STO Connector	60
		Mechanical Specifications	23
		Minimizing Conducted, Radiated, and System Noise for EMC/CE Compliance	38
		Minimum Load Inductance specifications	21
		Modes of Operation	21
		Motor Connector	
		Mating Connector Part Numbers	46
		Motor Function Relative to STO Input State	64
		Motor Power Output Connector	39
		Brushless Motor Connections	40
		DC Brush Motor Connections	43
		Mating Connector Part Numbers	39
		Pinout	39
		Stepper Motor Connections	44
		Three Phase Stepper Motor Connections	45
		Motor Supply Connections	30
		Motor Supply Connector	30
		Mating Connector Part Numbers	30
		Wiring Specifications	30
		Motor Supply specifications	21
		Mounting and Cooling	23



Specifications		Startup Validation Testing	64
Analog Encoder (Feedback Connector)	50	Timing	65
Analog Input 0 (Aux I/O Connector)	79	Typical Configuration	61
Analog Output 0 (Aux I/O Connector)	78	Storage	13
Analog Outputs [-EB1]	97	Sync-Related Commands	84
Brake Control Relay	59	Sync Port Cables	84
Control Board Fuses	107	Sync Ports	84
Control Supply Connector Wiring	29	System part number	13
Differential Analog Inputs [-EB1]	98	System Power Requirements	22
Digital Inputs (Aux I/O Connector)	75		
Digital Inputs [-EB1]	94	<b>T</b>	
Digital Outputs (Aux I/O Connector)	72	Table of Contents	3
Digital Outputs [-EB1]	90	Thermistor Input (Feedback Connector)	54
High-Speed Inputs	77	Thermistor Input Pin on the Feedback Connector	54
Motor Supply Connector Wiring	30	Thermistor Input Schematic	54
PSO (Aux I/O Connector)	70	Three Phase Stepper Motor Configuration	45
PSO [-EB1]	99	Three Phase Stepper Motor Connections (Motor Power Output Connector)	45
RS-422 Encoder (Feedback Connector)	48,68	TM3	31
Sine Wave Encoder (Feedback Connector)	50	TM5	31
Square Wave Encoder (Feedback Connector)	48,68	Transformer Options	31
STO Electrical Specifications	61	Travel Limit Input (Feedback Connector)	56
Unit Weight	23	TTL Outputs Schematic (PSO)	100
Square Wave Encoder	48	TV0.3-28	31
Square Wave Encoder (Auxiliary I/O Connector)	68	TV0.3-28-56-ST Transformer	31
Square Wave Encoder Inputs Schematic (Aux I/O Connector)	68	TV0.3-28-56-ST Transformer (160 VDC Bus)	34
Square Wave Encoder Schematic (Feedback Connector)	48	TV0.3-28-56-ST Transformer (40 VDC Bus)	32
Square Wave Encoder Specifications (Feedback Connector)	48,68	TV0.3-28-56-ST Transformer (80 VDC Bus)	33
Standard Features	19	TV0.3-28 Transformer (40 VDC Bus)	35
Stepper Motor Configuration	44	TV0.3-56	31
Stepper Motor Connections (Motor Power Output Connector)	44	TV0.3-56 Transformer (80 VDC Bus)	36
Stepper Motor Phasing	44-45	Two Axis Joystick Interface	102
STO	60	Two Axis Joystick Interface (to the I/O board of two drives)	103
Connector Pinout	60	Typical STO Configuration	61
Diagnostics	65		
Electrical Specifications	61	<b>U</b>	
External Delay Timer	63	Unit Weight	23
Functional Description	63	Use	26
Mating Connector Part Numbers	60	User Power Supply specifications	21
Motor Function Relative to the STO Input State	64		
Signal Delay	64	<b>W</b>	
Standards	62	Warranty and Field Service	109
Standards Data	62		

---

Wire Colors for Aerotech-Supplied Brushless Motor Cables	40
Wire Colors for Aerotech-Supplied DC Brush Motor Cables	43
Wire Colors for Aerotech-Supplied Stepper Motor Cables	44

*This page intentionally left blank.*