

Tube Processing with Extreme Speed & Precision

Engineered and optimized for high-throughput tubular processing applications, ASR1300 is the fastest and most capable rotary collet stage available. Now able to accept tubes with up to 4 mm outer diameter, ASR1300 accommodates Levin Type-D dead-length collets—so your workpiece has virtually zero axial motion when the collet opens and closes. This helps to reduce errors in the laser-cutting of stents, hypotubes, catheters and similar devices. ASR1300 has a maximum rated speed of 3000 rpm. With its high-torque, low-inertia design, it can accelerate from zero to 1500 rpm over a mere 90 degrees of travel, making ASR1300 considerably faster and more suitable than a spindle for tubular processing. Plus, ASR1300 is our lightest and most compact rotary collet stage, so it's ideal for integrating with high-throughput tube processing machines.

Key Applications

The ASR1300 is the lightest, fastest and most capable direct-drive rotary collet stage available. It's ideal for the high-throughput manufacturing of medical devices and tubular products, such as:

- Coronary stents
- Peripheral vascular stents
- Neurovascular stents
- Hypotubes
- Coronary microcatheters
- Guidewires

KEY FEATURES:

- ◆ Accepts tube DIAMETERS FROM
 0.1 mm TO 4 mm NEW
- ◆ Compatible with TYPE-D COLLETS
- Minimal collet runout LESS THAN25 µm TIR
- Optimized for MAXIMUM ACCELERATION
- Features a CLEAR, THROUGH-BORE APERTURE & GUIDE
 SYSTEM for tube feedthrough
- ULTRA-COMPACT, lightweight design simplifies integration & improves throughput
- Available with OPTIONAL WATER
 COOLING for maximum throughput

ASR1300 SERIES SPECIFICATIONS

| Mechanical Specifications | | |
|--------------------------------------------|---------------------|--------------------------------------------------------|
| Travel | | ±360° continuous |
| Accuracy | | ±73 μrad (±15 arc sec) |
| Bidirectional Repeatability | | ±10 μrad (±2 arc sec) |
| Maximum Speed ⁽¹⁾ | | 3000 rpm |
| Acceleration | Peak ⁽¹⁾ | 8000 rad/s² |
| | Continuous(1)(2) | 3300 rad/s² |
| Maximum Torque (Continuous) | | 0.7 N·m |
| Tube Capacity | | Up to 4 mm Collet ID |
| Load Capacity ⁽³⁾ | Radial | 2.0 kg |
| | Axial | 0.50 kg |
| | Moment | 0.75 N·m |
| Analog Outputs | | 0 (Available with -EB1 I/O Expansion Board, see below) |
| Rotor Inertia (Unloaded) | | 0.00013 kg·m² |
| Stage Mass | | 2.8 kg |
| Collet Type | | Type D (Louis Levin & Sons™) Normally-Open |
| Collet Runout ⁽⁴⁾ | | <25 μm |
| Minimum System Air Pressure ⁽⁵⁾ | | 100 psig |
| Material | | Hard Coat Aluminum; Stainless Steel; Polymer |
| MTBF | | 10,000 Hours |

Notes:

- 1. Requires selection of appropriate amplifier with sufficient voltage, current, and encoder frequency. Over 2000 rpm requires HPe drive or Npaq.
- 2. Based on steady-state temperature rise of motor by 20°C from ambient with Water Cooling option. Continuous accel limit is 1600 rad/s² without Water Cooling option.
- 3. Maximum loads are mutually exclusive. Loading limits are due to the collet chuck mechanism. Contact Aerotech directly if part load requirement exceeds specifications.
- 4. TIR of precision gage pin in an ultra-precision collet. Measured 3 mm away from collet face at 100 psig applied air pressure for ASR1300.
- 5. The ASR1300 contains a collet chuck mechanism that is normally-open. Collet mechanism requires air to close collet chuck. Air supply must be dry (0°F dew point), oil-less air or 99.99% pure nitrogen. Air or nitrogen must be filtered to 1 micron particle size or better.

| Electrical Specifications | |
|----------------------------------|---------------------------------------------------------------|
| Drive System | Brushless, Direct-Drive Servomotor |
| Feedback System | 1 Vpp, Incremental Noncontact Optical Encoder, 7200 lines/rev |
| Maximum Bus Voltage | 320 VDC |



ASR1300 ORDERING OPTIONS

Water Cooling (Optional)

-WC Motor water cooling

Connector (Required)

-CN1 4-pin HPD motor and 25-pin D feedback connectors

-CN2 25-pin D motor and 25-pin D feedback connectors

Mounting Plate (Optional)

-MP1 Mounting plate - no water cooling-MP2 Mounting plate - with water cooling

Mounting Orientation (Required)

-MT1 Normal mounting

-MT2 Left-side mounting

-MT3 Inverted mounting

-MT4 Right-side mounting

Integration (Required)

Aerotech offers both standard and custom integration services to help you get your system fully operational as quickly as possible. The following standard integration options are available for this system. Please consult Aerotech if you are unsure what level of integration is required or if you desire custom integration support with your system.

-TAS Integration - Test as system

Testing, integration and documentation of a group of components as a complete system that will be used together (ex: drive, controller and stage). This includes parameter file generation, system tuning and documentation of the system configuration.

-TAC Integration - Test as components

Testing and integration of individual items as discrete components. This is typically used for spare parts, replacement parts or items that will not be used or shipped together (ex: stage only). These components may or may not be part of a larger system.

Accessories (to be ordered as separate line item)

Collet-D-CLTxx Collet, Type-D, Part Sizes from 0.1 mm to 4 mm

CGF Collet and gripper filtration kit



ASR1300 SERIES DIMENSIONS

